

---

# WG - SERIES COMBINATION GAS/ELECTRIC WALL-MOUNT

## INSTALLATION INSTRUCTIONS

### MODELS:

|         |         |         |
|---------|---------|---------|
| WG3S2-A | WG3S2-B | WG3S2-C |
| WG4S2-A | WG4S2-B | WG4S2-C |
| WG5S2-A | WG5S2-B | WG5S2-C |

---



## WARNING

READ ALL INSTRUCTIONS CAREFULLY BEFORE BEGINNING THE INSTALLATION.

THE INSTALLATION MUST COMPLY WITH THESE INSTRUCTIONS AND THE REQUIREMENTS OF ALL GOVERNING CODES AND ORDINANCES FOR THE INSTALLATION LOCATION.

IT IS THE RESPONSIBILITY OF INSTALLER TO KNOW AND UNDERSTAND ALL OF THESE REQUIREMENTS.

FAILURE TO DO SO COULD CREATE A HAZARD RESULTING IN PROPERTY DAMAGE, BODILY INJURY, OR DEATH.



Bard Manufacturing Company, Inc.  
Bryan, Ohio 43506  
*Since 1914...Moving ahead just as planned.*

Manual No.: 2100-587B  
Supersedes: 2100-587A  
File: Volume III, Tab 20  
Date: 09-20-13

# CONTENTS

---

|                                                   | Page    |                                                                                    | Page    |
|---------------------------------------------------|---------|------------------------------------------------------------------------------------|---------|
| Getting Other Information and Publications .....  | 4       | 21. Standard Orifice Sizing & High Altitude Derate .....                           | 29      |
| WG Series Model Nomenclature .....                | 5       | 22. Conversion of Gas Input BTUH From High to Low Rating .....                     | 31      |
| Ventilation Options .....                         | 5       | 23. Measuring Air Temperature Rise .....                                           | 31      |
| Air Conditioning Module Options .....             | 6       | 24. Filters .....                                                                  | 32      |
| 1. Important .....                                | 9       | 25. Compressor Control Module .....                                                | 32 & 33 |
| 2. Application .....                              | 9       | 26. Lighting & Shutdown Instructions .....                                         | 34      |
| 3. Duct Work .....                                | 9       | 27. Service Agency Procedures .....                                                | 35      |
| 4. High Altitude Applications .....               | 9       | 28. Maintaining Unit in Good Working Order ..                                      | 35 & 36 |
| 5. Transportation Damage .....                    | 10      | 29. Replacement Parts .....                                                        | 36      |
| 6. Installation .....                             | 10      | 30. Sequence of Operation – Heating .....                                          | 37      |
| 7. Wall Mounting .....                            | 10      | 31. Sequence of Operation – Cooling .....                                          | 37      |
| 8. Mounting the Unit .....                        | 10      | 32. Indoor Blower Operation .....                                                  | 38      |
| 9. Clearances .....                               | 16      | Start Up                                                                           |         |
| 10. Vent Terminal and Combustion Inlet Hood ..... | 17      | Application .....                                                                  | 40      |
| 11. Optional Vertical Venting .....               | 17      | Important Installer Note .....                                                     | 40      |
| 12. Vent Resizing Instructions .....              | 18      | High & Low Pressure Switch .....                                                   | 40      |
| 13. Fresh Air Intake .....                        | 18      | Three Phase Scroll Compressor .....                                                | 41      |
| 14. Condensate Drain .....                        | 18      | Troubleshooting                                                                    |         |
| 15. Wiring – Main Power .....                     | 19      | Compressor Solenoid .....                                                          | 42      |
| 16. Wiring – Low Voltage Wiring .....             | 20      | Fan Blade Setting Dimensions .....                                                 | 42      |
| 17. Thermostats .....                             | 20      | Removal of Fan Shroud .....                                                        | 42      |
| 18. Gas Supply & Piping .....                     | 26      | ECM™ Motors .....                                                                  | 43      |
| 19. Manifold Pressure Adjustment .....            | 27      | ECM™ Motors .....                                                                  | 44      |
| 20. Checking Gas Input Rate .....                 | 27 & 28 | 33. Pressure Service Ports .....                                                   | 45      |
|                                                   |         | 34. R-410A Refrigerant Charge .....                                                | 46      |
|                                                   |         | 35. Low NOx Burner Assembly "N" Suffix Models Only – U.S. Installations Only ..... | 46      |
|                                                   |         | Index – Wiring Diagrams .....                                                      | 47      |
|                                                   |         | Wiring Diagrams .....                                                              | 48 – 59 |

# CONTENTS

---

| <b>FIGURES</b> | <b>Page</b>                                                | <b>TABLES</b> | <b>Page</b>                                            |
|----------------|------------------------------------------------------------|---------------|--------------------------------------------------------|
| Figure 1       | Unit Dimensions .....                                      | Table 1       | Specifications .....                                   |
| Figure 2A      | Mounting Instructions – WG3S2 .....                        | Table 2       | Minimum Installation Clearances .....                  |
| Figure 2B      | Mounting Instructions–WG4S2 & WG5S2 ....                   | Table 3       | Thermostat Wire Size .....                             |
| Figure 3       | Combustible Clearance .....                                | Table 4       | Wall Thermostat .....                                  |
| Figure 4       | Wall Mounting Instructions .....                           | Table 5       | Length of Standard Pipe Threads .....                  |
| Figure 5       | Wall Mounting Instructions .....                           | Table 6       | Gas Pipe Sizes – Natural Gas .....                     |
| Figure 6       | Common Wall Mounting Installations ...                     | Table 7       | Natural Gas Derate Capacities<br>For All Models .....  |
| Figure 7       | Location of Vent Terminal in Shipping ..                   | Table 8       | Natural Gas Orifice Tables– WG3,4,5S ..                |
| Figure 8       | Vent Terminal & Combustion<br>Air Intake .....             | Table 8A      | Natural Gas Orifice Tables .....                       |
| Figure 9       | Installation of Flexible Conduit .....                     | Table 9       | Indoor Blower Performance .....                        |
| Figure 10A     | Low Voltage Wiring - No Vent .....                         | Table 10      | Integrated Furnace & Blower<br>Control Operation ..... |
| Figure 10B     | Low Voltage Wiring - CRV .....                             | Table 11      | Fan Blade Dimensions .....                             |
| Figure 10C     | Low Voltage Wiring - Economizer .....                      | Table 12      | Cooling Pressures .....                                |
| Figure 10D     | Low Voltage Wiring - ERV .....                             |               |                                                        |
| Figure 11      | Gas Pipe Connection .....                                  |               |                                                        |
| Figure 12      | Proper Piping Practice .....                               |               |                                                        |
| Figure 13      | Access Internal Filter .....                               |               |                                                        |
| Figure 14      | Lighting & Shutdown Instruction Label ..                   |               |                                                        |
| Figure 15      | Top View of Gas Control .....                              |               |                                                        |
| Figure 16      | Sequence of Operation – Electronic<br>Blower Control ..... |               |                                                        |
| Figure 17      | Furnace Control Board &<br>Blower Control .....            |               |                                                        |
| Figure 18      | Fan Blade .....                                            |               |                                                        |
| Figure 19      | Control Disassembly .....                                  |               |                                                        |
| Figure 20      | Winding Test .....                                         |               |                                                        |
| Figure 21      | Drip Loop .....                                            |               |                                                        |
| Figure 22      | Low NOx Insert .....                                       |               |                                                        |

# Getting Other Information and Publications

---

These publications can help you install the furnace. You can usually find these at your local library or purchase them directly from the publisher. Be sure to consult current edition of each standard.

National Fuel Gas Code ..... ANSI Z223.1 / NFPA 54

National Electrical Code ..... ANSI / NFPA 70

Standard for the Installation ..... ANSI / NFPA 90A  
of Air Conditioning and Ventilating Systems

Standard for Warm Air ..... ANSI / NFPA 90B  
Heating and Air Conditioning Systems

Standard for Chimneys, ..... NFPA 211  
Fireplaces, Vents, and Solid Fuel Burning Appliances

Load Calculation for ..... ACCA Manual J  
Residential Winter and Summer Air Conditioning

Duct Design for Residential ..... ACCA Manual D  
Winter and Winter Air Conditioning and Equipment  
Selection

Canadian Electrical Code ..... CSA C22.1

Canadian Installation Code.....CAN/CGA B149

## FOR MORE INFORMATION, CONTACT THESE PUBLISHERS:

**ACCA**      **Air Conditioning Contractors of America**  
1712 New Hampshire Avenue, NW  
Washington, DC 20009  
Telephone: (202) 483-9370

**ANSI**      **American National Standards Institute**  
11 West Street, 13th Floor  
New York, NY 10036  
Telephone: (212) 642-4900  
Fax: (212) 302-1286

**ASHRAE**      **American Society of Heating Refrigerating,  
and Air Conditioning Engineers, Inc.**  
1791 Tullie Circle, NE.  
Atlanta, GA 30329-2305  
Telephone: (404) 636-8400  
Fax: (404) 321-5478


**NFPA**      **National Fire Protection Association**  
Batterymarch Park  
P.O. Box 9101  
Quincy, MA 02269-9901  
Telephone: (800) 344-3555  
Fax: (617) 984-7057

**CSA**      **Canadian Standards Association**  
178 Rexdale Boulevard  
Rexdale, Ontario  
Canada. M9W 1R3  
Telephone: (416) 447-4044

BARD MANUFACTURING COMPANY, INC.  
BRYAN, OHIO 43506 USA

# WALL MOUNT GAS/ELECTRIC GENERAL

## MODEL NUMBER NOMENCLATURE



\*125,000 BTU input model is not NOx certified.

## VENTILATION OPTIONS

| Models                                    |                            | WG3S, WG4S, WG5S         |
|-------------------------------------------|----------------------------|--------------------------|
| Description                               | Factory Installed Code No. | Field Installed Part No. |
| Blank-Off Plate                           | B                          | WGSBOP-5                 |
| Commercial Ventilator - Multiple Position | V                          | WGSCRVMP-5               |
| Economizer - Fully Modulating ①           | E                          | WGSEIFM-5                |
| Energy Recovery Ventilator - 230 Volt     | R                          | WGSERV-A5A               |
| Energy Recovery Ventilator - 460 Volt     | R                          | WGSERV-C5A               |

① Low ambient control is required with economizer for low temperature compressor operation.

## AIR CONDITIONING MODULE OPTIONS

| ①<br>CCM | ②<br>HPC | ③<br>LPC | ④<br>LAC | Factory Installed<br>Code | Field Installed<br>Part |
|----------|----------|----------|----------|---------------------------|-------------------------|
| STD      | STD      | STD      |          | X                         | N/A                     |
| STD      | STD      | STD      | •        | H                         | CMA-28                  |

STD = Standard equipment.

① CCM Compressor control module has adjustable 30 second to 5 minute delay-on-break timer. On initial power up, or any time the power is interrupted, the delay-on-make will be 2 minutes plus 10% of the delay-on-break setting. There is no delay-on-make during routine operation of the unit. The module also provides the lockout feature (with 1 retry) for high and/or low pressure controls, and a 2 minute timed bypass for low pressure control.

② HPC High pressure control is auto reset. Always used with compressor control module (CCM) which is included. See note ①.

③ LPC Low pressure control is auto reset. Always used with compressor control module (CCM) which is included. See note ①.

④ LAC Low ambient control permits cooling operation down to 0°F.



## CAUTION

During the initial firing of the burners there will probably be some amount of smoke issued to the circulating air stream as the result of residual oil burning off of the heat exchanger tubes. This oil is required during the forming process of the stainless steel heat exchanger tubes to facilitate the bending. OSHA or the National Toxicology Program does not list the oil as a carcinogen. In vapor form this may be irritating to the eyes or could cause headaches. This is a one-time occurrence, and ventilation of the space may be required depending upon the space being conditioned.

**TABLE 1**  
**SPECIFICATIONS**

| <b>Models</b>                           | <b>WG3S2-A</b> | <b>WG3S2-B</b> | <b>WG3S2-C</b> | <b>WG4S2-A</b> | <b>WG4S2-B</b> | <b>WG4S2-C</b> | <b>WG5S2-A</b> | <b>WG5S2-B</b> | <b>WG5S2-C</b> |
|-----------------------------------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|----------------|
| <i>Electrical Rating - 60 Hz</i>        | 230/208-60-1   | 230/208-60-3   | 460-60-3       | 230/208-60-1   | 230/208-60-3   | 460-60-3       | 230/208-60-1   | 230/208-60-3   | 460-60-3       |
| <i>Operating Voltage Range</i>          | 197-253        | 187-253        | 414-506        | 197-253        | 187-253        | 414-506        | 197-253        | 187-253        | 414-506        |
| <i>Minimum Circuit Ampacity</i>         | 27             | 23             | 12             | 36             | 27             | 14             | 45             | 31             | 15             |
| <i>* Field Wire Size</i>                | 8              | 10             | 14             | 8              | 10             | 12             | 8              | 8              | 12             |
| <i>Ground Wire Size</i>                 | 10             | 10             | 14             | 10             | 10             | 12             | 10             | 10             | 12             |
| <i>** Delay Fuse - Max.</i>             | 40             | 30             | 15             | 45             | 40             | 20             | 60             | 45             | 20             |
| <i>Compressor</i>                       |                |                |                |                |                |                |                |                |                |
| <i>Compressor Type</i>                  | Scroll         | Scroll         | Scroll         | Scroll         | Scroll         | Scroll         | Scroll         | Scroll         | Scroll         |
| <i>Volts</i>                            | 230/208        | 230/208        | 460            | 230/208        | 230/208        | 460            | 230/208        | 230/208        | 460            |
| <i>Rated Load Amps</i>                  | 11.6 / 12.9    | 8.8 / 9.9      | 6.7            | 15.0 / 17.8    | 10.4 / 11.8    | 5.4            | 20.9 / 23.0    | 12.8 / 14.1    | 6.2            |
| <i>Branch Circuit Selection Current</i> | 15.3           | 11.7           | 5.8            | 21.2           | 14.1           | 6.5            | 27.2           | 16.5           | 7.2            |
| <i>Lock Rotor Amps</i>                  | 83             | 73             | 38             | 104            | 83             | 41             | 153            | 110            | 52             |
| <i>Fan Motor and Compressor</i>         |                |                |                |                |                |                |                |                |                |
| <i>Fan Motor - HP/RPM/SPD</i>           | 1/3-850-2      | 1/3-850-2      | 1/3-850-1      | 1/3-850-2      | 1/3-850-2      | 1/3-850-1      | 1/3-850-2      | 1/3-850-2      | 1/3-850-1      |
| <i>Blower Motor - Amps</i>              | 2.5            | 2.5            | 1.3            | 2.5            | 2.5            | 1.3            | 2.5            | 2.5            | 1.3            |
| <i>Fan - DIA/CFM</i>                    | 24" - 2700     | 24" - 2700     | 24" - 2700     | 24" - 2700     | 24" - 2700     | 24" - 2700     | 24" - 2700     | 24" - 2700     | 24" - 2700     |
| <i>Motor and Evaporator</i>             |                |                |                |                |                |                |                |                |                |
| <i>Blower Motor - HP/RPM/SPD</i>        | 1/2 Variable   | 1/2 Variable   | 1/2 Variable   | 3/4 Variable   | 3/4 Variable   | 3/4 Variable   | 3/4 Variable   | 3/4 Variable   | 3/4 Variable   |
| <i>Blower Motor - Amps</i>              | 3.6            | 3.6            | 3.6            | 4.7            | 4.7            | 4.7            | 6.0            | 6.0            | 6.0            |
| <i>CFM Cooling &amp; E.S.P.</i>         | 1100           | 1100           | 1100           | 1500           | 1500           | 1500           | 1700           | 1700           | 1700           |
| <i>Filter Sizes (Inches)</i>            | 20 x 30 x 2    | 20 x 30 x 2    | 20 x 30 x 2    | 20 x 30 x 2    | 20 x 30 x 2    | 20 x 30 x 2    | 20 x 30 x 2    | 20 x 30 x 2    | 20 x 30 x 2    |
| <i>Charge (R-410A)</i>                  | 156            | 156            | 156            | 240            | 240            | 240            | 246            | 246            | 246            |


\* 75 degree C Copper wire size

\*\* Maximum time delay fuse or HACR Type circuit breaker

**FIGURE 1**  
**UNIT DIMENSIONS**

| UNIT        | A    | B     | C     | D     | E     | F     | G     | H    | I  | J     | K     | L     | M     | N     | O     | P   | Q   | R    |
|-------------|------|-------|-------|-------|-------|-------|-------|------|----|-------|-------|-------|-------|-------|-------|-----|-----|------|
| WG3S2       | 9.88 | 29.88 | 15.88 | 27.25 | 43.81 | 14.88 | 31.63 | 87.5 | 30 | 33.38 | 28.75 | 14.12 | 15.44 | 15.31 | 42.88 | 4.5 | 2.5 | 3.75 |
| WG4S2/WG5S2 |      |       |       |       |       |       | 41.63 | 97.5 |    | 43.38 | 38.75 |       |       |       |       |     |     |      |

| UNIT        | S  | T     | U    | V    | W  | X     | Y    | Z    | AA    | BB   | CC | DD   | EE    | FF   | GG   | HH   | II   |
|-------------|----|-------|------|------|----|-------|------|------|-------|------|----|------|-------|------|------|------|------|
| WG3S2       | 16 | 3.75  | 3.88 | 24.9 | 42 | 17.34 | 8.44 | 2.25 | 12.19 | 3.25 | 10 | 7.25 | 40.25 | 1.13 | 1.25 | 2.75 | 0.44 |
| WG4S2/WG5S2 |    | 13.75 |      | 34.9 |    |       |      |      |       |      |    |      |       |      |      |      |      |



MIS-3240 A

## 1. IMPORTANT

The equipment covered in this manual is to be installed by trained, experienced service and installation technicians. All duct work or portions thereof not in the conditioned space should be properly insulated in order to both conserve energy and prevent condensation or moisture damage.

## 2. APPLICATION

This is a fan-assisted forced air gas furnace with electric air conditioning for outdoor installation. A fan-assisted furnace is equipped with an integral mechanical means to draw products of combustion through the combustion chamber and heat exchanger. The furnace installation must conform with local building codes and ordinances or, in their absence, with the National Fuel Gas Code ANSI Z223.1 or CAN/CGA-B149.1, latest edition, and the National Electrical Code ANSI/NFPA-7 or CSA C22.1, latest edition. It is the personal responsibility and obligation of the purchaser to contact a qualified installer to assure that installation is adequate and is in conformance with governing codes and ordinances.

## 3. DUCT WORK

The unit is designed for use with or without duct work. See Warning on Page 9. Flanges are provided for attaching the supply and return ducts. These instructions explain the recommended method to install the air cooled self-contained electric air conditioning and gas heating unit and the electrical wiring connections and gas piping to the unit. The refrigerant system is completely assembled and charged. All internal wiring is complete.

These instructions and any instructions packaged with any separate equipment required to make up the entire heating/cooling system should be carefully read before beginning the installation. Note particularly "Starting Procedure" and any tags and/or labels attached to the equipment.

All duct work, supply and return, must be properly sized for the design airflow requirement of the equipment. Air Conditioning Contractors of America (ACCA) is an excellent guide to proper sizing.

Refer to Table 9 in this Manual for maximum static pressure available for duct design.

See Figure 3 and clearance information in Section 9 and Table 2 for additional information.

Design the duct work according to methods given by the Air Conditioning Contractors of America (ACCA). When duct runs through unheated spaces, it should be insulated with a minimum of one-inch of insulation. Use insulation with a vapor barrier on the outside of the insulation. Flexible joints should be used to connect the duct work to the equipment in order to keep the noise transmission to a minimum.

## WARNING

In all cases, there must be a metal duct connection made to the supply air flange, and a one inch clearance to combustibles must be maintained to this duct connection.

For free blow applications, a metal sleeve must be used in the wall opening itself, again maintaining a one inch clearance to combustibles.

Failure to use the sheet metal can cause fire resulting in property damage, injury, or death.

A one-inch clearance to combustible material for the first three feet of duct attached to the outlet air frame is required. See Wall Mounting Instructions and Figures 2, 2A, 3 and 3A for further details.

Ducts through the walls must be insulated and all joints taped or sealed to prevent air or moisture entering the wall cavity.

Some installations may not require any return air duct. A metallic return air grille is required with installations not requiring a return air duct. The spacing between louvers on the grille shall not be larger than 5/8 inch.

Any grille that meets with the 5/8 inch louver criteria may be used. It is recommended that Bard Return Air Grille or Return Filter Grille be installed when no return duct is used. Contact distributor or factory for ordering information. If using a return air filter grille, filters must be of sufficient size to allow a maximum velocity of 400 fpm.

*NOTE: If no return air duct is used, applicable installation codes may limit this cabinet to installation only in a single story structure.*

## 4. HIGH ALTITUDE APPLICATIONS

Ratings of gas utilization equipment are based on sea level operation and need not be changed for operation at elevations up to 6,000 feet. For operation at elevations above 6,000 feet and in the absence of specific recommendations from the local authority having jurisdiction, equipment ratings shall be reduced as specified in Section 21.

## 5. TRANSPORTATION DAMAGE

All units are packed securely in shipping container. All units should be carefully inspected upon arrival for damage. In the event of damage, the consignee should:

1. Note on delivery receipt of any damage to container.
2. Notify carrier promptly, and request an inspection.
3. In case of concealed damage, the carrier must be notified as soon as possible within 15 days after delivery.
4. Claims for any damage, apparent or concealed, should be filed with the carrier, using the following supporting documents:
  - A. Original Bill of Lading, certified copy, or indemnity bond.
  - B. Original paid freight bill of indemnity in lieu thereof.
  - C. Original invoice or certified copy thereof showing trade and other discounts or deductions.
  - D. Copy of the inspection report issued by carrier's representative at the time damage is reported to carrier.

## 6. INSTALLATION

Size of unit for proposed installation should be based on heat loss/heat gain calculations made according to methods of Air Conditioning Contractors of America (ACCA). The air duct should be installed in accordance with the Standards of the National Fire Protection Association for the Installation of Air Conditioning and Ventilating Systems of Other Than Residence Type, NFPA No. 90A, and Residence Type Warm Air Heating and Air Conditioning Systems, NFPA No. 90B. Where local regulations are at a variance with instructions, installer should adhere to local codes.

## 7. WALL MOUNTING INFORMATION

1. Two holes for the supply and return air openings must be cut through the wall as detailed in Figure 4.
2. On wood-frame walls, the wall construction must be strong and rigid enough to carry the weight of the unit without transmitting any unit vibration.
3. Concrete block walls must be thoroughly inspected to insure that they are capable of carrying the weight of the installed unit.

## 8. MOUNTING THE UNIT

1. These units are secured by wall mounting brackets which secure the unit to the outside wall surface at both sides. A bottom mounting bracket is provided for ease of installation but is not required.

### CAUTION

If the bottom bracket is used, be certain the bracket is secured to the outside wall surface in a way sufficient to support the entire weight of the unit during installation until side mounting brackets are secured.

2. The WG3S2, WG4S2 and WG5S2 models are suitable for 0 inch clearance on the installation mounting wall and to the top. For all models the supply air duct flange and the first 3 feet of supply air duct require a minimum of 1-inch clearance to combustible material.

### WARNING

Failure to provide the one inch clearance between the supply duct and a combustible surface for the first three feet of duct can result in fire causing damage, injury or death.

3. Locate and mark lag bolt locations and bottom mounting bracket location.
4. Mount bottom mounting bracket.
5. Hook top rain flashing under back bend of top. Top rain flashing is shipped secured to the right side of the back.
6. Position unit in opening and secure with 5/16 lag bolts; use 7/8 inch diameter flat washers on the lag bolts. Use lag bolts long enough to support the unit's weight when mounted to the structure. This length may be dependant on the type of construction.
7. Secure rain flashing to wall and caulk across entire length of top. See Figure 3.
8. On side-by-side installations, maintain a minimum of 20 inches clearance on right side to allow access to control panel and burner compartment, and to allow proper airflow to the outdoor coil. Additional clearance may be required to meet local or national codes.

SEAL WITH BEAD OF CAULKING ALONG ENTIRE LENGTH OF TOP.

RAIN FLASHING SUPPLIED

TOP

FOAM AIR SEAL

WALL STRUCTURE

1" CLEARANCE ON ALL FOUR SIDES OF SUPPLY AIR DUCT IS REQUIRED FROM COMBUSTIBLE MATERIALS

1.000 MIN.

SUPPLY AIR DUCT

NO CLEARANCE NECESSARY

RETURN AIR DUCT

NOTE: IT IS RECOMMENDED THAT A BEAD OF SILICONE CAULKING BE PLACED BEHIND THE SIDE MOUNTING FLANGES AND UNDER TOP FLASHING AT TIME OF INSTALLATION.

VESTIBULE ACCESS PANEL

CONTROL PANEL

WALL

FLANGE SCREWS (12)

2.063

16.000

32.000

5.438

SUPPLY AIR DUCT

Ø2.750 GAS OPENING (OPTIONAL)

5.938

2.813

11.188

16.000

6.088

Ø2.000 L. VOLTAGE (OPTIONAL)

16.000

13.625

16.000

5.188

2.813

16.000

9.500

UNIT SUPPORT

Ø2.750 H. VOLTAGE (OPTIONAL)

2.000

7.438

.250

2.250

6.438

30.000

42.875

28.500

1.938

12.000


6.563

17.000

28.188

Manual 2100-587B  
Page 11 of 59

**FIGURE 2B**



NOTE:  
IT IS  
OF SI  
BEHIN  
FLANG  
AT TI

MIS-2329

**FIGURE 3**  
**COMBUSTIBLE CLEARANCE**



MIS-1714


## WARNING

A **minimum** of one (1) inch clearance must be maintained between the supply air duct and combustible materials. This is required for the first three (3) feet of ducting.

It is important to insure that the one (1) inch minimum spacing is maintained at all points.


Failure to do this could result in overheating the combustible material and may result in a fire causing damage, injury or death.

**FIGURE 4**  
**WALL MOUNTING INSTRUCTIONS**




MIS-1475

**FIGURE 5**  
**WALL MOUNTING INSTRUCTIONS**



MIS-2124

**FIGURE 6**  
**COMMON WALL MOUNTING INSTALLATIONS**



MIS-1474

## 9. CLEARANCES

Minimum clearances, as specified in Table 2, must be maintained from adjacent structures to provide adequate fire protection, adequate combustion air, and room for service personnel.

While minimum clearances are acceptable for safety reasons, they may not allow adequate air circulation around the unit for proper operation in the cooling mode. Whenever possible, it is desirable to allow additional clearance, especially around the condenser inlet and discharge openings. DO NOT install the unit in a location that will permit discharged air from the condenser to recirculate to the condenser inlet.


**TABLE 2**  
**MINIMUM INSTALLATION CLEARANCES**

|                                                                   |                     |
|-------------------------------------------------------------------|---------------------|
| Outlet Duct (from combustible materials)                          | 1 inch first 3 feet |
| Vent Terminal (from combustible materials)                        | * 17 inches         |
| Condenser Inlet                                                   | 20 inches           |
| Top                                                               | See Figure 3        |
| Burner Service                                                    | 20 inches           |
| Combustible Base (Wood or Class A, B or C roof covering material) | 0 inches            |
| * See Figure 3                                                    |                     |

### **WARNING**

Clearances from combustible materials must be maintained as specified. Failure to maintain clearances could cause fire resulting in property damage, injury, or death.

**FIGURE 7**  
**LOCATION OF VENT TERMINAL IN SHIPPING**



## 10. VENT TERMINAL AND COMBUSTION AIR INLET HOOD

The vent terminal is shipped in the burner compartment. See Figure 7. Remove the two shipping screws and separate the two-piece assembly. Install the vent terminal by using the four screws provided. **Make sure gasket is in place.** See Figure 8. The combustion air intake hood is factory installed.

## 11. OPTIONAL VERTICAL VENTING

With the optional vertical venting kit (VVK-5) this unit may be vented vertically through a roof or overhang. The kit includes a stainless steel transition drain tee, silicone sealant, and drain tubing.

If unit is installed with vertical vent kit, annually inspect the vent system and drain. Replace any portion of the vent system that shows signs of deterioration. Make sure drain is open and free of obstruction.




## CAUTION

Vent terminal must be installed as shown in Figure 8 for proper operation of the heating system.

**NOTE: The inner vent hood gasket is designed to stretch over and seal around the combustion air blower outlet. This is a very critical seal to prevent water and flue products from entering the unit. Care must be taken to insure this gasket is in place and sealing properly.**

FIGURE 8  
VENT TERMINAL AND COMBUSTION AIR INTAKE



## 12. VENT RESIZING INSTRUCTIONS

When an existing furnace is removed from a venting system servicing other appliances, the venting system is likely to be too large to properly vent the remaining attached appliances.

The following steps shall be followed with each of the appliances remaining connected to the common venting system, placed in operation one at a time while the other appliances remaining connected to the common venting system are not in operation.

1. Seal any unused openings in the venting system.
2. Inspect the venting system for proper size and horizontal pitch, as required in the National Fuel Gas code, ANSI Z223.1 or the CAN/CGA B149 Installation Codes and these instructions. Determine that there is no blockage or restriction, leakage, corrosion and other deficiencies which could cause an unsafe condition.
3. In so far as is practical, close all building doors and windows and all doors between the space in which the appliance(s) connected to the venting system are located and other spaces of the building. Turn on clothes dryers and any appliances not connected to the venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
4. Follow the lighting instructions. Place the appliance being inspected in operation. Adjust thermostat so appliance shall operate continuously.
5. Test for draft hood equipped appliance spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle.
6. After it has been determined that each appliance connected to the venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliances to their previous conditions of use.
7. If improper venting is observed during any of the above tests, the venting system must be corrected.

## 13. FRESH AIR INTAKE

All units are built with fresh air inlet slots punched in the service panel.

The default unit is built with blank-off plates installed. All capacity, efficiency and cost of operation information as required for Department of Energy "Energyguide" Fact Sheets is based upon the fresh air blank-off plate in place and is recommended for maximum energy efficiency.

One of several other ventilation options may be installed. Refer to model number and/or supplemental installation instructions.

## 14. CONDENSATE DRAIN

A plastic drain hose extends from the drain pan at the top of the unit down to the unit base. There are openings in the unit base for the drain hose to pass through. In the event the drain hose is connected to a drain system of some type, it must be an open or vented type system to assure proper drainage.

## 15. WIRING – MAIN POWER

### WARNING

For your personal safety, turn off electric power at service entrance panel before making any electrical connections. Failure to do so could result in electric shock or fire.

Refer to unit rating plate for wire sizing information and maximum fuse or “HACR” type circuit breaker size. Each outdoor unit is marked with a “Minimum Circuit Ampacity”. This means that the field wiring used must be sized to carry that amount of current. All models are suitable only for connection with copper wire. Each unit and/or wiring diagram will be marked - “Use Copper Conductors Only”. These instructions **must be** adhered to. Refer to the National Electrical Code (NEC) for complete current carrying capacity data on the various insulation grades of wiring material. All wiring must conform to NEC and all local codes.

The electrical data lists fuse and wire sizes (75° C copper) for all models.

The unit rating plate lists a “Maximum Time Delay Relay Fuse” or “HACR” type circuit breaker that is to be used with the equipment. The correct size must be used for proper circuit protection and also to assure that there will be no nuisance tripping due to the momentary high starting current of the compressor motor.

The disconnect access door on this unit may be locked to prevent unauthorized access to the disconnect. To convert for the locking capability bend the tab located in the bottom left hand corner of the disconnect opening under the disconnect access panel straight out. This tab will now line up with the slot in the door. When shut, a padlock may be placed through the hole in the tab preventing entry.

See “Start Up” section for important information on three phase scroll compressor start ups.

### WARNING

Failure to provide an electrical power supply shut off means could result in electric shock or fire.

## ELECTRICAL GROUNDING

When installed, the furnace must be electrically grounded in accordance with local codes or in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70, or Canadian Electrical Code, CSA22.1, latest edition. Use a copper wire from green ground wire on the furnace to a grounded connection in the service panel or a properly driven and electrically grounded ground rod. See Table 1 for proper ground wire size.

### WARNING

Failure to provide a proper electrical ground could result in electric shock or fire.

## FIELD INSTALLED EQUIPMENT

Wiring to be done in the field between the furnace and devices not attached to the furnace, or between separate devices which are field installed and located, shall conform with the temperature limitation for Type T wire {63 degrees F rise (36 degrees C)} when installed in accordance with the manufacturer’s instructions.


## INSTALLATION OF FLEXIBLE CONDUIT THROUGH RETURN AIR OPENING

*NOTE: To allow proper clearance between the control panel and any vent options, 90° conduit fittings must be used on the back of the control panel.*

## INSTALLING CONDUIT (See Figure 9.)

1. Remove conduit access panel if required to gain access to area behind control panel.
2. Remove low voltage and high voltage knockouts located in rear of control panel.
3. Run low voltage conduit through 7/8 bushing located in conduit entrance plate and secure to low voltage opening in rear of control panel.
4. Run high voltage conduit through 1-3/4 bushing located in conduit entrance plate and secure to high voltage opening in rear of control panel.
5. Replace conduit access panel if required to complete installation.
6. Seal around conduit in conduit entrance plate.

**FIGURE 9  
INSTALLATION OF FLEXIBLE CONDUIT**



MIS 1553

## 16. WIRING – LOW VOLTAGE WIRING

### Low Voltage Connection

These units use a 24-volt AC low voltage circuit. The “R” terminal is the *hot* terminal and the “C” terminal is *grounded*.

“G” terminal is the *fan input*.

“Y” terminal is the *economizer input (where equipped)*.

“Y1” terminal is the *compressor input*.

“Y2” terminal is the *compressor staging solenoid input*.

“R” terminal is 24 VAC *hot*.

“C” terminal is 24 VAC *grounded*.

“A” terminal is the *ventilation input*. This terminal energizes any factory or field installed vent option.

“2” terminal is the *alarm output*.

“W1” terminal is the *gas heat input*.

### 230/208 VOLT UNITS

All models are equipped with dual primary voltage transformers. All equipment leaves the factory wired on 240V tap. For 208V operation, reconnect from 240V to 208V tap. The acceptable operating voltage range for the 240V and 208V taps are:

| TAP | RANGE     |
|-----|-----------|
| 240 | 253 – 206 |
| 208 | 220 – 187 |

**NOTE:** The voltage should be measured at the field power connection point in the unit and while the unit is operating at full load (maximum amperage operating condition).

### 460 VOLT UNITS

All models are equipped with single primary voltage transformers and no rewiring is required.

### Direct Digital Controls (DDC)

For total and proper control using DDC, a total of 5 controlled outputs are required (4 if no ventilation is installed).

#### LOW VOLTAGE CONNECTIONS FOR DDC CONTROL

|                     |                    |
|---------------------|--------------------|
| Fan Only            | Energize G         |
| Cooling Mode (Low)  | Energize G, Y1     |
| Cooling Mode (High) | Energize G, Y1, Y2 |
| Heating Mode        | Energize W1        |
| Ventilation         | Energize G, A      |

## 17. THERMOSTATS

**TABLE 3  
THERMOSTAT WIRE SIZE**


| Transformer VA | FLA | Wire Gauge | Maximum Distance In Feet |
|----------------|-----|------------|--------------------------|
| 50             | 2.1 | 20 gauge   | 45                       |
|                |     | 18 gauge   | 60                       |
|                |     | 16 gauge   | 100                      |
|                |     | 14 gauge   | 160                      |
|                |     | 12 gauge   | 250                      |

**TABLE 4  
WALL THERMOSTAT**

| Thermostat                | Predominant Features                                                                                                      |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------|
| 8403-058<br>(TH5220D1151) | 2 stage Cool; 2 stage Heat<br>Electronic Non-Programmable<br>Auto or Manual changeover                                    |
| 8403-060<br>(1120-445)    | 3 stage Cool; 3 stage Heat<br>Programmable/Non-Programmable Electronic<br>HP or Conventional<br>Auto or Manual changeover |

FIGURE 10A  
LOW VOLTAGE WIRING - NO VENT


## Low Voltage Wiring - No Ventilation Package



MIS-2330 D

**FIGURE 10B**  
**LOW VOLTAGE WIRING - COMMERCIAL ROOM VENTILATOR**

## Low Voltage Wiring - Multi-position Commercial Room Ventilator




△ 1 MUST INSTALL JUMPER FOR 8403-058 OR OTHER THERMOSTAT THAT DOES NOT HAVE OCCUPANCY OUTPUT.

△ 2 INSTALL IF YOU REQUIRE VENTILATION ANYTIME BLOWER IS ON.

MIS-2433 F


FIGURE 10C  
LOW VOLTAGE WIRING - ECONOMIZER

## Low Voltage Wiring - EIFM ECONOMIZER



MIS-2432 C


**FIGURE 10D**  
**LOW VOLTAGE WIRING - ENERGY RECOVERY VENTILATOR**



- 1 MUST INSTALL JUMPER FOR 8403-058 OR OTHER THERMOSTAT THAT DOES NOT HAVE OCCUPANCY OUTPUT.
- 2 INSTALL IF YOU REQUIRE VENTILATION ANYTIME BLOWER IS ON.

MIS-2434 C

**FIGURE 11**  
**GAS PIPE CONNECTION**



## 18. GAS SUPPLY AND PIPING

### GENERAL RECOMMENDATIONS


1. Be sure the gas line complies with the local codes and ordinances, or in their absence with the National Fuel Gas Code, ANSI Z223.1, or Natural Gas Installation Code, CAN/CGA B149.1, or Propane Installation Code B149.2, latest edition.
2. A sediment trap or drip leg must be installed in the supply line to the furnace.
3. A ground joint union shall be installed in the gas line adjacent to and upstream from the gas valve and downstream from the manual shut off valve.
4. An 1/8" NPT plugged tapping accessible for test gauge connection shall be installed immediately upstream of the gas supply connection to the furnace for the purpose of determining the supply gas pressure. This can be omitted if local codes permit use of plugged tapping in gas valve inlet.
5. Install listed manual shut off valve in the supply gas line external to and immediately upstream of the furnace. See Figure 11.
6. Use steel or wrought iron pipe and fittings.
7. **DO NOT** thread pipe too far. Valve distortion or malfunction may result from excess pipe within the control. Use pipe joint compound resistant to the action of liquefied petroleum gases on male threads only. **DO NOT** use Teflon tape. See Table 5 and Figure 12.

**TABLE 5  
LENGTH OF STANDARD  
PIPE THREADS (INCHES)**

| Pipe Size | Effective Length of Thread | Overall Length of Thread |
|-----------|----------------------------|--------------------------|
| 3/8       | 1/2                        | 9/16                     |
| 3/4       | 1/2 - - 9/16               | 13/16                    |
| 1         | 9/16                       | 1                        |

**FIGURE 12  
PROPER PIPING PRACTICE**

PROPER PIPING PRACTICE



MIS-897

8. Refer to Table 6 for Gas Pipe Sizes for natural gas. If more than one appliance is supplied from a single line size, capacity must equal or exceed the combined input to all appliances, and the branch lines feeding the individual appliances properly sized for each input.

**THIS PRODUCT MUST BE GAS PIPED BY  
A LICENSED PLUMBER OR GAS FITTER  
IN THE COMMONWEALTH OF  
MASSACHUSETTS.**

**TABLE 6  
GAS PIPE SIZES - NATURAL GAS**

| Length of Pipe - Feet | Pipe Capacity - BTU per Hour Input Pipe Size |         |         |           |
|-----------------------|----------------------------------------------|---------|---------|-----------|
|                       | 1/2"                                         | 3/4"    | 1"      | 1-1/4"    |
| 10                    | 132,000                                      | 278,000 | 520,000 | 1,050,000 |
| 20                    | 92,000                                       | 190,000 | 350,000 | 730,000   |
| 30                    | 73,000                                       | 152,000 | 285,000 | 590,000   |
| 40                    | 63,000                                       | 130,000 | 245,000 | 500,000   |
| 50                    | 56,000                                       | 115,000 | 215,000 | 440,000   |
| 60                    | 50,000                                       | 105,000 | 195,000 | 400,000   |
| 70                    | 46,000                                       | 96,000  | 180,000 | 370,000   |
| 80                    | 43,000                                       | 90,000  | 170,000 | 350,000   |
| 100                   | 38,000                                       | 79,000  | 150,000 | 305,000   |

### CHECKING THE GAS PIPING

Before turning gas under pressure into piping, all openings from which gas can escape should be closed. Immediately after turning on gas, the system should be checked for leaks. This can be done by watching the 1/2 cubic foot test dial and allowing 4 minutes to show any movement, and by soaping each pipe connection and watching for bubbles. If a leak is found, make the necessary repairs immediately and repeat the above test. The furnace must be isolated from the gas supply piping system by closing the manual shut off valve on the combination gas control valve during pressure testing of the gas supply piping system at pressures up to 1/2 PSIG. The furnace and its individual shut off valve must be disconnected from supply piping and supply piping capped during any pressure testing of supply piping system at test pressures in excess of 1/2 PSIG.

Defective pipes or fittings should be replaced and not repaired. Never use a flame or fire in any form to locate gas leaks; use a soap solution.

After the piping and meter have been checked completely, purge the system of air. **DO NOT** bleed air inside the furnace. **Be sure to check and relight all the gas pilots on other appliances that may have been extinguished because of interrupted gas supply.**

### **PROPANE (LP) GAS CONVERSION**

*This unit may be converted in the field for use with Propane (LP) gas. Propane gas conversion kit number WGCK-1 is designed for conversions of units installed from 0 – 6,000 feet elevations. Propane gas conversion kit number WGCK-2 is designed for conversions of units installed from 6,001 – 10,000 feet elevations. These kits may be purchased from your local distributor.*



## **WARNING**

When converting from propane (LP) gas to natural gas, the gas orifice spuds and gas valve spring must be replaced and the gas valve regulator pressure must be adjusted correctly. Failure to do so can result in fire, injury or death. Refer to Tables 8 and 8A for proper orifice sizing.

Natural gas spring kit, Part number 5603-007, can be purchased through your local distributor.

### **19. MANIFOLD PRESSURE ADJUSTMENT**

You will need a 0 to 15 inch water manometer with 0.1 inch resolution and a 1/8" NPT manual shut off valve to measure actual manifold pressure.



## **WARNING**

Correct manifold pressure is necessary for proper ignition and burner operation. Failure to accurately adjust pressure could cause heat exchanger failure.

1. Turn off gas at equipment shut off valve in gas supply line just ahead of furnace.
2. Remove plug from outlet pressure tap in gas control or gas manifold.
3. Install 1/8" NPT manual shut off valve in hole vacated by plug. Make sure shut off valve is in off position.
4. Attach manometer to 1/8" NPT manual shut off valve just installed.

5. Slowly open equipment shut off valve in gas supply line just ahead of furnace. Start furnace following "Operating Instructions" on front door.
6. Slowly open 1/8" NPT manual shut off valve leading to manometer.
7. Read manifold pressure on manometer.
8. Adjust manifold pressure by turning gas control regulator adjusting screw clockwise to increase pressure or turning counterclockwise to decrease pressure. Manifold pressure must be within allowable range as follows:
  - Natural gas manifold pressure must be between 3.2 and 3.8 inches W.C. Rated pressure is 3.5 inches.
  - Propane gas (LP) manifold pressure must be between 9.7 and 10.3 inches W.C. Rated pressure is 10 inches.

*NOTE: For natural gas, if gas flow rate can't be properly set within these pressure ranges then you must change main burner orifices to obtain proper gas flow rate.*

9. Shut off furnace. Turn off gas at equipment shut off valve in gas supply line just ahead of furnace. Install outlet pressure tap plug in gas control. Turn on gas.
10. Check regulator adjustment cover screw and gas control plug for gas leaks. Use a commercial soap solution made for leak detection.

### **20. CHECKING GAS INPUT RATE**

It is the installer's responsibility to see that the BTU input rate of the furnace is properly adjusted. Under-firing could cause inadequate heat, excessive condensation or ignition problems. Overfiring could cause sooting, flame impingement or overheating of heat exchanger.



## **WARNING**

Failure to adjust furnace to the proper firing rate could cause heat exchanger failure.

Depending on your local gas heating value and elevation, you may need to adjust manifold pressure or change orifices to get proper gas input rate. Check with your local gas supplier to determine heating value (BTU/cu. ft.) of natural gas in your area.

*NOTE: If furnace is being installed at an altitude of more than 6,000 feet above sea level, you must derate the furnace. See Section 21 "Standard Orifice Sizing and High Altitude Derate".*

## NATURAL GAS INPUT RATE

Natural gas heating value (BTU/cu. ft.) can vary significantly. Before starting natural gas input check, obtain gas heating value at your location from local supplier. You will need a stopwatch to measure actual gas input.

1. Gas supply pressure must be between 5 and 7 inches W.C. for natural gas.
2. Turn off all other gas appliances. You may leave pilots on.
3. Start furnace following "Operating Instructions" on front door.
4. Let furnace warm up for 6 minutes.
5. Locate gas meter. Determine which dial has the least cubic feet of gas and how many cubic feet per revolution it represents. This is usually one-half, one or two cubic feet per revolution.
6. With stopwatch, measure time it takes to consume two cubic feet of gas.
  - If dial is one-half cubic foot per revolution, measure time for four revolutions.
  - If dial is one cubic foot per revolution, measure time for two revolutions.
  - If dial is two cubic feet per revolution, measure time for one revolution.
7. Divide this time by two. This gives average time for one cubic foot of gas to flow through meter.  
Example: If it took 58 seconds for two cubic feet to flow, it would take 29 seconds for one cubic foot to flow.

8. Calculate gas input using this formula:

Gas Heating Value (BTU/cu. ft.)

$$\text{Gas input} = \frac{\text{Gas Heating Value (BTU/cu. ft.)} \times 3,600 \text{ sec/hr}}{\text{Time (Seconds for one cubic foot of gas)}} = \text{BTU/hour}$$

Example:

Assume it took 29 seconds for one cubic foot of gas to flow and heating value of 1,000 BTU/cu. ft.

$$\text{Gas input} = \frac{1,000 \times 3,600}{29} = 124,138 \text{ BTU}$$

If you left no other pilots on, this is the furnace gas input.

9. If you left water heater, dryer or range pilots on, allow for them in calculating correct furnace gas input. A quick way is to allow 1,000 BTU per hour for a water heater, 500 BTU per hour for dryer and 500 BTU per hour for each range burner pilot.

Example:

If you left gas water heater, dryer, two range burner pilots and one oven pilot on, allow:

|                       |                          |
|-----------------------|--------------------------|
| Water heater pilot    | 1,000 BTU per hour       |
| Dryer pilot           | 500 BTU per hour         |
| 2 range burner pilots | 1,000 BTU per hour       |
| 1 range oven pilot    | 500 BTU per hour         |
|                       | <hr/> 3,000 BTU per hour |

Subtracting 3,000 BTU per hour from 124,138 BTU per hour measured above equals 121,138 BTU per hour. This would be the correct furnace gas input after allowing for pilots left on.

10. Manifold pressure may be adjusted within the range of 3.2 inches W.C. to 3.8 inches W.C. to get rated input  $\pm 2$  percent. See Section 19, "Manifold Pressure Adjustment". If you cannot get rated input with manifold pressure within the allowable range, you must change orifices.

## PROPANE (LP) GAS INPUT RATE



Propane (LP) gas installations do not have gas meters to double check input rate. Measure manifold pressure adjustment with an accurate manometer. Failure to accurately adjust pressure could cause heat exchanger failure, asphyxiation, fire or explosion, resulting in damage, injury or death.

1. Make sure you have proper main burner orifices.
2. Gas supply pressure must be between 11 and 13 inches W.C. for propane (LP) gas.
3. Start furnace following "Operating Instructions" on front door.
4. Let furnace warm up for 6 minutes.
5. Adjust manifold pressure to 10.0 W.C.  $\pm 0.3$  inches W.C. See Section 19, "Manifold Pressure Adjustment".



Do not set Propane (LP) manifold pressure at 11.0 inches W.C. It could cause heat exchanger failure.

## 21. STANDARD ORIFICE SIZING AND HIGH ALTITUDE DERATE

This furnace is shipped with fixed gas orifices for use with Natural Gas and sized for 1000 BTU/cubic foot gas. Make sure actual gas input does not exceed rating plate input. You may need to change orifices to get correct gas input. Whether you do or not depends on input, and your gas heat value at standard conditions and elevation. Consult your local gas supplier for gas heat value and any special derating requirements. See Section 20 for more information.

At higher altitudes, the density of the air is reduced. Therefore, for proper combustion, the quantity of gas

burned in the furnace must also be reduced. This is called derating. This unit must be derated when installed at altitudes greater than 6,000 feet above sea level. A high altitude pressure switch must also be installed for operation above 6,000 feet. High altitude pressure switch kit number 8620-189 is designed for this application.

It is the installer's responsibility to see that the furnace input rate is adjusted properly. Derating must be achieved by reducing the size of the main burner orifices. Derating the furnace by adjusting the manifold pressure lower than the range specified in the Section 19, "Manifold Pressure Adjustment" is considered to be an improper procedure.

**TABLE 7  
NATURAL GAS DERATE CAPACITIES  
FOR ALL MODELS**

| <b>NATURAL GAS DERATE CAPACITIES</b> |                  |             |             |             |             |             |             |
|--------------------------------------|------------------|-------------|-------------|-------------|-------------|-------------|-------------|
| <b>WG Rated Input</b>                | <b>Sea Level</b> | <b>1000</b> | <b>2000</b> | <b>3000</b> | <b>4000</b> | <b>5000</b> | <b>6000</b> |
| <b>45,000</b>                        | 45,000           | 43,560      | 42,120      | 40,680      | 39,600      | 38,880      | 37,980      |
| <b>50,000</b>                        | 50,000           | 48,400      | 46,800      | 45,200      | 44,000      | 43,200      | 42,200      |
| <b>67,500</b>                        | 67,500           | 65,340      | 63,180      | 61,020      | 59,400      | 58,320      | 56,970      |
| <b>75,000</b>                        | 75,000           | 72,600      | 70,200      | 67,800      | 66,000      | 64,800      | 63,300      |
| <b>90,000</b>                        | 90,000           | 87,120      | 84,240      | 81,360      | 79,200      | 77,760      | 75,960      |
| <b>100,000</b>                       | 100,000          | 96,800      | 93,600      | 90,400      | 88,000      | 86,400      | 84,400      |
| <b>112,500</b>                       | 112,500          | 108,900     | 105,300     | 101,700     | 99,000      | 97,200      | 94,950      |
| <b>125,000</b>                       | 125,000          | 121,000     | 117,000     | 113,000     | 110,000     | 108,000     | 105,500     |

**TABLE 8  
NATURAL GAS ORIFICE TABLES  
FOR MODELS WG3S, WG4S AND WG5S**

| Factory Standard Input                                                                 | Gas Heat* Value<br>BTU/Cu. Ft. | Up to 6,000 Feet No Changes Except for BTU Content | 6,001 to 8,000 Feet Requires Pressure Switch Change and Orifice Change<br>Based on BTU Content | 8,001 to 10,000 Feet Requires Pressure Switch Change and Orifice Change<br>Based on BTU Content |
|----------------------------------------------------------------------------------------|--------------------------------|----------------------------------------------------|------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|
| 25000 BTU Per Burner                                                                   | 700-749                        | 2.90                                               | 2.80                                                                                           | 2.70                                                                                            |
|                                                                                        | 750-799                        | 2.80                                               | 2.70                                                                                           | 2.60                                                                                            |
|                                                                                        | 800-849                        | 2.70                                               | 2.60                                                                                           | 2.50                                                                                            |
|                                                                                        | 850-899                        | 2.60                                               | 2.50                                                                                           | 2.45                                                                                            |
|                                                                                        | 900-949                        | 2.50                                               | 2.45                                                                                           | (2.40)                                                                                          |
|                                                                                        | 950-999                        | 2.45                                               | (2.40)                                                                                         | 2.35                                                                                            |
|                                                                                        | 1000-1049**                    | (2.40)                                             | 2.35                                                                                           | [2.30]                                                                                          |
|                                                                                        | 1050-1100                      | [2.30]                                             | 2.25                                                                                           | 2.20                                                                                            |
|                                                                                        | Pressure Switch                | Standard (.55)                                     | Order 8620-189 High Altitude Pressure Switch Kit (.42)                                         |                                                                                                 |
| (2.40) is the standard factory installed orifice size                                  |                                |                                                    | [2.30] orifices are shipped with the unit for field installed optional 10% derate              |                                                                                                 |
|                                                                                        |                                |                                                    |                                                                                                |                                                                                                 |
| Optional 10% Field Converted Derate                                                    | Gas Heat* Value<br>BTU/Cu. Ft. | Up to 6,000 Feet No Changes Except for BTU Content | 6,001 to 8,000 Feet Requires Pressure Switch Change and Orifice Change<br>Based on BTU Content | 8,001 to 10,000 Feet Requires Pressure Switch Change and Orifice Change<br>Based on BTU Content |
| 22500 BTU Per Burner                                                                   | 700-749                        | 2.75                                               | 2.70                                                                                           | 2.60                                                                                            |
|                                                                                        | 750-799                        | 2.70                                               | 2.60                                                                                           | 2.50                                                                                            |
|                                                                                        | 800-849                        | 2.60                                               | 2.50                                                                                           |                                                                                                 |
|                                                                                        | 850-899                        | 2.50                                               | 2.45                                                                                           | (2.40)                                                                                          |
|                                                                                        | 900-949                        | (2.40)                                             | 2.35                                                                                           | [2.30]                                                                                          |
|                                                                                        | 950-999                        | 2.35                                               | [2.30]                                                                                         | 2.25                                                                                            |
|                                                                                        | 1000-1049**                    | [2.30]                                             | 2.25                                                                                           | 2.20                                                                                            |
|                                                                                        | 1050-1100                      | 2.25                                               | 2.25                                                                                           | 2.20                                                                                            |
|                                                                                        | Pressure Switch                | Standard (.55)                                     | Order 8620-189 High Altitude Pressure Switch Kit (.42)                                         |                                                                                                 |
| [2.30] orifices are shipped with the unit for field installed optional 10% input rate. |                                |                                                    | (2.40) is the factory installed orifice size for full rated input                              |                                                                                                 |

\* At standard conditions: 30.00 inches Mercury, 60F, saturated, .60 specific gravity.

\*\* All Natural Gas factory orifice sizing and standard input ratings based on nominal 1025 BTU/cu ft gas and sea level conditions

All other orifice sizes shown are available as individual items. See Orifice tables below for part numbers and number required.

| Bard Part No. | Orifice Size (mm) | Orifice Diameter |
|---------------|-------------------|------------------|
| 9010-092      | 2.10              | 0.0826           |
| 9010-088      | 2.15              | 0.0846           |
| 9010-087      | 2.20              | 0.0866           |
| 9010-086      | 2.25              | 0.0885           |
| 9010-082      | 2.30              | 0.0905           |
| 9010-085      | 2.35              | 0.0925           |
| 9010-079      | 2.40              | 0.0945           |
| 9010-084      | 2.45              | 0.0964           |
| 9010-093      | 2.50              | 0.0984           |
| 9010-094      | 2.60              | 0.1024           |
| 9010-095      | 2.70              | 0.1063           |
| 9010-096      | 2.75              | 0.1082           |
| 9010-097      | 2.80              | 0.1102           |
| 9010-098      | 2.90              | 0.1142           |

| No. of Orifices Required Based on Unit Input Rating |
|-----------------------------------------------------|
| 45,000 (2)                                          |
| 50,000 (2)                                          |
| 68,000 (3)                                          |
| 75,000 (3)                                          |
| 90,000 (4)                                          |
| 100,000 (4)                                         |
| 113,000 (5)                                         |
| 125,000 (5)                                         |

## 22. CONVERSION OF GAS INPUT BTUH FROM HIGH TO LOW RATING

All the derated WG series units are produced with maximum BTUH input orifices installed. To field convert input, a change to main burner orifices is required.

*NOTE: No change to air orifices is necessary. A set of low input orifices is shipped with every unit. They will be found packaged in a bag behind the burner door. Refer to the unit rating plate to confirm the proper orifice size. Proper installation of the orifices is detailed as follows:*

- A. Shut off electrical supply to the unit.
- B. Shut off gas supply to the unit.
- C. Remove burner access panel.
- D. Disconnect gas valve from gas supply piping.
- E. Disconnect the two wires from the gas valve.
- F. Remove the manifold assembly so that orifices are now accessible and remove orifices.
- G. Apply a modest amount of pipe compound to the new orifices and screw them into the manifold.
- H. To assemble burner reverse steps A through G.



**WARNING**  
Failure to follow these instructions could create a hazard resulting in property damage, bodily injury, or death.

## 23. MEASURING AIR TEMPERATURE RISE

Air temperature rise (supply air temperature minus return air temperature) must be within allowable air temperature rise range specified on furnace rating plate and in Table 1.

You will need 2 thermometers with 1 degree resolution capable of reading up to 200 degrees F. Check thermometers to make sure they agree, or compensate accordingly.

Follow this procedure:

1. Open supply air registers and return air grilles. Make sure the registers and grilles are free of obstruction from rugs, carpets, drapes or furniture.


2. Set balancing dampers in supply duct system.
3. Check duct work for obstructions or leaks.
4. Make sure filters are clean and in place.
5. Place one thermometer in supply air plenum approximately 2 feet from furnace. Locate thermometer tip in center of plenum to insure proper temperature measurement.
6. Place second thermometer in return air duct approximately 2 feet from furnace. Locate thermometer tip in center of duct to insure proper temperature measurement.
7. Set room thermostat on highest temperature setting. Operate furnace 10 minutes. Record supply air and return air temperatures.
8. Calculate air temperature rise by subtracting return air temperature from supply air temperature.
  - If air temperature rise is above the temperature rise range on rating plate, furnace is overfired or has insufficient airflow. Check gas input following the instructions in Section, "Checking Gas Input Rate". If air temperature rise is still above temperature rise range specified, more heating airflow is needed. Check duct work and grilles to make sure all are properly sized.
  - If air temperature rise is below the temperature rise range on rating plate, furnace is underfired or has too much airflow. Check gas input following the instructions in Section, "Checking Gas Input Rate". If air temperature rise is still below temperature rise range specified, less heating airflow is needed. Adjust dampers or grilles as needed.
  - After making adjustments, you must check air temperature rise to verify that resulting air temperature rise is within allowable range. If air temperature rise is still outside the temperature rise range specified on rating plate, check duct system design with a qualified heating engineer. It may be necessary to re-size the duct work. Recheck air temperature rise after revising duct systems.

9. Set room thermostat to desired setting.

10. Remove thermometers and seal duct work holes.

*NOTE: Failure to seal holes could result in reduced system performance.*

**FIGURE 13**  
**ACCESS INTERNAL FILTER**



## 24. FILTERS

A 2" thick throwaway filter is supplied with each unit. This filter is installed by removing the filter access panel. (See Figure 13.)

Replacement filters are available through your dealer.

## 25. COMPRESSOR CONTROL MODULE

The compressor control module is standard on the models covered by this manual. The compressor control is an anti-short cycle/lockout timer with high and low pressure switch monitoring and alarm relay output.

### Adjustable Delay On Make And Break Timer

On initial power up or anytime power is interrupted to the unit, the *delay on make* period begins, which will be 2 minutes plus 10% of the *delay on break* setting. When the delay on make is complete and the high pressure and low pressure switches are closed, the compressor contactor is energized. Upon shutdown, the delay or break timer starts and prevents restart until the delay on break and delay on make periods have expired.

During routine operation of the unit with no power interruptions, the compressor will operate on demand with no delay.

### HIGH PRESSURE SWITCH AND LOCKOUT SEQUENCE (Standard Feature)

If the high pressure switch opens, the compressor contactor will de-energize immediately. The lockout timer will go into a *soft lockout* and stay in soft lockout until the high pressure switch closes **and** the delay-on-make time has expired. If the high pressure switch opens again in this same operating cycle the unit will go into *manual lockout* condition and the alarm circuit will energize. Recycling the wall thermostat resets the manual lockout.

### LOW PRESSURE SWITCH, BYPASS, AND LOCKOUT SEQUENCE

If the low pressure switch opens for more than 120 seconds, the compressor contactor will de-energize and go into a soft lockout. Regardless the state of the low pressure switch, the contactor will reenergize after the delay-on-make time delay has expired. If the low pressure switch remains open or opens again for longer than 120 seconds the unit will go into manual lockout condition and the alarm circuit will energize. Recycling the wall thermostat resets the manual lockout.

## ALARM OUTPUT

Alarm terminal is output connection for applications where alarm signal is desired. This terminal is powered whenever compressor is locked out due to HPC or LPC sequences as described.

*NOTE: Both high and low pressure switch controls are inherently automatic reset devices. The high pressure switch and low pressure switch cut out and cut in settings are fixed by specific air conditioner or heat pump unit model. The lockout features, both soft and manual, are a function of the Compressor Control Module.*

## ADJUSTMENTS

### ADJUSTABLE DELAY-ON-MAKE AND DELAY-ON-BREAK TIMER

The potentiometer is used to select Delay-on-Break time from 30 seconds to 5 minutes. Delay-on-Make (DOM) timing on power-up and after power interruptions is equal to 2 minutes plus 10% of Delay-on-Break (DOB) setting:

|                          |                  |     |
|--------------------------|------------------|-----|
| 0.5 minute (30 seconds)  | DOB = 123 second | DOM |
| 1.0 minute (60 seconds)  | DOB = 126 second | DOM |
| 2.0 minute (120 seconds) | DOB = 132 second | DOM |
| 3.0 minute (160 seconds) | DOB = 138 second | DOM |
| 4.0 minute (240 seconds) | DOB = 144 second | DOM |
| 5.0 minute (300 seconds) | DOB = 150 second | DOM |

## PHASE MONITOR

All units with three phase scroll compressors are equipped with a three phase line monitor to prevent compressor damage due to phase reversal.

The phase monitor in this unit is equipped with two LEDs. If the “Y” signal is present at the phase monitor and phases are correct, the green LED will light.

If phases are reversed, the red fault LED will be lit and compressor operation is inhibited.

If a fault condition occurs, reverse two of the supply leads to the unit. Do not reverse any of the unit factory wires as damage may occur.

### Optional Low Ambient Control

An optional low ambient control is available for both factory and field installed options. The low ambient control is to be applied to the WG3S/WG4S/WG5S models when operation below 50° outdoor conditions are anticipated. Without this device, the evaporating pressure would fall off, and the indoor coil would ice over.

The fan cycling control cycles the fan motor on, once the liquid refrigerant pressure reaches 350 psig, and off, once it has dropped to 225 psig. It will continue to cycle between these parameters depending on outdoor temperatures and the load/stage of the system.

This cycling maintains a minimum liquid pressure affecting the minimum suction pressure. This effect insures an evaporating temperature that is slightly above the point of ice formation on the evaporator.

## 26. LIGHTING AND SHUTDOWN INSTRUCTIONS

FIGURE 14  
INSTRUCTION LABEL

### FOR YOUR SAFETY READ BEFORE OPERATING

**WARNING:** If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do NOT try to light the burner by hand.
- B. BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

#### WHAT TO DO IF YOU SMELL GAS


- \* Do not try to light any appliance.
- \* Do not touch any electric switch; do not use any phone in your building.
- \* Immediately call your supplier from a neighbor's phone. Follow the gas supplier's instructions.

\* If you cannot reach your gas supplier; call the fire department.

- C. Use only your hand to push in or move the gas control lever. Never use tools. If the lever will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

### OPERATING INSTRUCTIONS

1. STOP! Read the safety information above on this label.
2. Set the thermostat to lowest setting.
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an ignition device which automatically lights the burner. Do NOT try to light the burner by hand.



5. Remove control access panel.
6. Push in gas control knob slightly and turn clockwise to "OFF".  
NOTE: Knob cannot be turned to "OFF" unless knob is pushed in slightly. Do not force.
7. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
8. Turn gas control knob counterclockwise to "ON".
9. Replace control access panel.
10. Turn on all electric power to the appliance.
11. Set thermostat to desired setting.
12. If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.

### TO TURN OFF GAS TO APPLIANCE

1. Set the thermostat to lowest setting.
2. Turn off all electric power to the appliance if service is to be performed.
3. Remove control access panel.
4. Push in gas control lever slightly and move to "OFF". Do not force.
5. Replace control access panel.

7961-509

## 27. SERVICE AGENCY PROCEDURES

### CAUTION

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

### WARNING

Follow these procedures before inspecting furnace.


- Turn room thermostat to its lowest or off setting.
- Turn off manual gas shut off valve.
- Wait at least 5 minutes for furnace to cool if it was recently operating.
- Turn off furnace electrical power; failure to do so could result in injury or death.

#### MAIN BURNER

Observe the main burners in operation. The flame should be mostly “blue” with possibly a little orange (not yellow) at the tips of the flame. The flames should be in the center of the heat exchanger tubes and not impinging on the heat exchanger surfaces themselves.

Observe the fire until the blower starts (there is a normal delay period until the heat exchanger warms up). There should be no change in the size or shape of the flame. If there is any wavering or blowing of the flame on blower start-up, it is an indication of a possible leak in the heat exchanger.

**FIGURE 15**  
**TOP VIEW OF GAS CONTROL**



#### BURNERS / HEAT EXCHANGER / FLUE GAS PASSAGE WAYS

The burners, heat exchanger and interior flue gas passages may be inspected using a light on small mirror or an extension handle. Remove the screws securing the inducer and collector box. Now inspect the upper tubes of the heat exchanger.

Check the exterior of the heat exchanger and the interior flue gas passages for any evidence of deterioration due to corrosion, cracking or other causes. If signs of sooting exist, remove the burners and clean the heat exchanger, as required.

## 28. MAINTAINING UNIT IN GOOD WORKING ORDER

The unit should be inspected annually by a qualified service agency.

### WARNING

Use replacement parts listed in the Replacement Parts list only. The use of incorrect parts could cause improper unit operation, resulting in damage, injury or death.

## WARNING

Disconnect electrical power before servicing unit. Failure to do so could result in electrical shock or death.

### ANNUAL MAINTENANCE

Routine inspection and maintenance procedures are the responsibility of the user and are outlined below.

1. Before inspecting unit:
  - a. Turn room thermostat to lowest or off setting.
  - b. Turn off equipment gas shut off valve.
  - c. Wait for unit to cool if it was recently operating.
  - d. Turn off electrical power to unit.
2. Inspect the following:
  - a. Vent terminal and combustion air intake terminal. Make sure both are free from obstructions.
  - b. Vertical Vent Applications – Inspect venting system. Make sure system has no holes, is physically sound and free from obstructions.
  - c. Make sure the supply and return air flange sleeves or duct work are securely fastened to unit and physically sound.
  - d. Supply and return grilles must be open and free from obstructions.
  - e. Inspect to make sure the unit is securely fastened to the wall. Seal any possible leaks between unit and wall with appropriate exterior sealing material.
  - f. Inspect burners, heat exchanger, induced draft blower, and induced draft blower collector box. There must be no obvious signs of deterioration.
  - g. Inspect all electrical connections and wiring.
  - h. Check all gas piping for leaks with soap solution used to detect leaks.
  - i. Inspect, clean, and repair as needed the entire blower assembly, air filters, draft inducer, cooling coils, and vent options (if installed).

### ROUTINE MAINTENANCE

1. Air Filters – Check the condition at least monthly when the unit is in use, and replace as necessary.
2. Lubrication Requirements – The indoor circulating air blower motor and outdoor circulating air fan motor are permanently lubricated and require no re-oiling. The combustion air blower motor requires no re-oiling.

## WARNING

Turn off electrical power supply to prevent injury from moving parts or electric shock.

### ROUTINE INSPECTION

1. Inspect the physical support of the unit annually to make sure it is securely fastened to the building. Also look for any obvious signs of deterioration.
2. Inspect the main burners at the beginning of each heating season and clean as necessary.
3. Inspect the vent terminal and combustion air intake hood for any obvious deterioration, to make sure it is free and clear of any obstructions.

## 29. REPLACEMENT PARTS

## WARNING

Use replacement parts listed in Replacement Parts list. Failure to do so could cause improper furnace operation, resulting in property damage, personal injury, or death.

Replacement parts for the gas/electric units are available through local distributors.

A replacement parts list manual is supplied with each unit. When ordering parts or making inquiries pertaining to any of the units covered by these instructions, it is very important to always supply the **complete** model number and serial number of the unit. This is necessary to assure that the correct parts (or an approved alternate part) are issued to the service agency.

### 30. SEQUENCE OF OPERATION – HEATING

On a call for heat from the thermostat, the induced draft blower is energized. Once sufficient draft is established, the pressure switch contacts close and the ignition system is energized. The direct spark ignitor will be energized allowing gas to flow. At the same time the main valve is energized, a 30-second blower delay timer is activated.

After this delay, the heating speed blower relay energizes. The blower will begin operating and remain in operation until the set delay time after the call for heat has been satisfied. This timing sequence guarantees blower on, blower off operation.

This unit is equipped with a flame roll-out switch, which is wired in series with the control circuit. This is a manual reset switch and is used for the purpose of preventing possible fire hazard in the event of a system malfunction. If this switch has opened the control circuit, there could be a possible system malfunction. Some of the conditions that might cause a roll-out to occur are blockage or sooting of primary heat exchanger, overfiring of furnace due to improper main burner orifices or incorrect manifold pressure, insufficient combustion air, or installation deficiencies with respect to return air duct design or sizing.

Once the problem has been resolved, reset the switch by pressing down on the reset button on top of the switch. See Figure 16 for additional information.

### 31. SEQUENCE OF OPERATION – COOLING

#### NON-ECONOMIZER

Stage 1 (Y1) cooling call activates Step 1 (partial capacity, 66%) of compressor capacity.

Stage 2 (Y2) cooling call activates Step 2 (full capacity, 100%) of compressor capacity.

#### WITH ECONOMIZER

Stage 1 (Y1) cooling call goes to economizer controls for decision:

- If Enthalpy Control decides outdoor conditions are suitable for free cooling, the economizer will operate.

- If Stage 2 cooling call is issued during economizer operation, the economizer will close and the compressor will go straight to Step 2 full capacity operation.

- If Enthalpy Control decides outdoor conditions are not suitable for free cooling, the economizer will not operate (or close) and Step 1 of the compressor will operate.

- If Stage 2 cooling call is issued, the compressor will shift to Step 2 full cooling capacity operation.

**FIGURE 16  
SEQUENCE OF OPERATION  
ELECTRONIC BLOWER CONTROL**

| ACTION                                                                | SYSTEM RESPONSE                                                                                                                                                                                                                                                                                                                                                 |
|-----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Thermostat calls for heat.<br>(W terminal is energized.)              | <ul style="list-style-type: none"><li>• Combustion air blower is energized.</li><li>• Air proving switch makes. Airflow is established.</li><li>• Ignition system is energized.</li><li>• Gas valve opens and main burner lights.</li><li>• Heat fan on delay timing begins. When timing is complete, the circulating fan is energized at heat speed.</li></ul> |
| Thermostat ends call for heat.                                        | <ul style="list-style-type: none"><li>• Ignition system is de-energized and gas valve closes.</li><li>• Combustion air blower is de-energized after postpurge timing.</li><li>• Heat fan off delay timing begins. When timing is complete, the circulating fan is de-energized.</li></ul>                                                                       |
| Thermostat begins call for cool.<br>(G and Y terminals re-energized.) | <ul style="list-style-type: none"><li>• Cooling contactor is energized.</li><li>• Circulating fan is energized on cool speed after cool fan on delay timing.</li></ul>                                                                                                                                                                                          |
| Thermostat begins call for fan.<br>(G terminal is de-energized.)      | <ul style="list-style-type: none"><li>• Circulating fan is de-energized</li></ul>                                                                                                                                                                                                                                                                               |
| Limit (flame rollout) opens.                                          | <ul style="list-style-type: none"><li>• Thermostat and ignition system are de-energized and gas valve closes.</li><li>• Combustion air blower and circulating fan heat speed are energized.</li></ul>                                                                                                                                                           |
| Limit (auto reset) or flame rollout<br>(manual reset) circuit closed. | <ul style="list-style-type: none"><li>• Combustion air blower remains energized for postpurge timing.</li><li>• The circulation fan remains energized for the selected delay off timing.</li><li>• Normal operation resumes.</li></ul>                                                                                                                          |

FIGURE 17



ATTACH JUMPER  
WIRE HERE FOR SINGLE  
SPEED OPERATION

MIS-1482

## 32. INDOOR BLOWER OPERATION

The indoor blower motor is a constant CFM variable speed direct drive motor. The motor is programmed to respond to individual thermostatic inputs that will determine the speed/airflow at which the motor operates. The motor software maintains the rated airflow across the range of allowable static whether the system is ducted or free blow. It will also maintain the temperature rise across the gas heat exchanger at the mid-point of the allowable rise range automatically. There are not adjustments that can be made in the field to adjust the airflows for any mode of operation.

TABLE 9

| MODEL | Rated ESP | Max ESP | ②<br>Continuous CFM | ③<br>Rated 1st Stage Cooling CFM | ④<br>Rated 2nd Stage Cooling CFM | Heating CFM ⑤ ⑥  |                  |                   |                   |
|-------|-----------|---------|---------------------|----------------------------------|----------------------------------|------------------|------------------|-------------------|-------------------|
|       |           |         |                     |                                  |                                  | 50,000 BTU Input | 75,000 BTU Input | 100,000 BTU Input | 125,000 BTU Input |
| WG3S2 | 0.15      | 0.50    | 800                 | 800                              | 1100                             | 1020             | 1250             | 1365              | 1410              |
| WG4S2 | 0.20      | 0.50    | 825                 | 1100                             | 1500                             | 1020             | 1250             | 1365              | 1410              |
| WG5S2 | 0.20      | 0.50    | 850                 | 1300                             | 1700                             | 1020             | 1250             | 1365              | 1410              |

- ① Motor will deliver consistent CFM through voltage supply range with no deterioration (197-253V for 230/208V models, 414-506V for 460V models).
- ② Continuous CFM is the total air being circulated during continuous (manual) fan mode.
- ③ Will occur automatically with a call for "Y1" signal from thermostat.
- ④ Will occur automatically with a call for "Y2" signal from thermostat.
- ⑤ Will occur automatically with a call for "W" signal from thermostat.
- ⑥ Constant CFM of Variable Speed Motor should maintain mid-rise temperature differential through range of allowable static.

**TABLE 10**  
**INTEGRATED FURNACE AND BLOWER CONTROL OPERATION**

**IGNITION SEQUENCE CONTROL**

|                                  |                                                                                                                                                                |
|----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Ignition Source                  | 24 VAC DSI                                                                                                                                                     |
| Flame Sensing                    | Remote                                                                                                                                                         |
| Timings                          |                                                                                                                                                                |
| - Prepurge                       | 15 seconds                                                                                                                                                     |
| - Postpurge                      | 30 seconds (0 if cycle terminated before valve "on")                                                                                                           |
| - Inter-trial purge              | 15 seconds                                                                                                                                                     |
| - Pressure switch proving period | 60 seconds                                                                                                                                                     |
| - Trials for ignition            | 3 per ignition sequence                                                                                                                                        |
| - Trial for ignition             | 7 seconds total time to prove flame                                                                                                                            |
| - Ignition sequence lockout      | 60 minutes (after 3 trials for ignition), auto reset<br>- can be reset during the 60 minute lockout period by opening thermostat circuit for 3 seconds or more |
| - Heat blower on - delay         | 30 seconds (timing starts when ignitor cycles off)                                                                                                             |
| - Heat blower off - delay        | 90, 120, 150 seconds selectable; factory set at 120                                                                                                            |
| - Cool blower on - delay         | 7 seconds                                                                                                                                                      |
| - Cool blower off - delay        | 60 seconds                                                                                                                                                     |
| - Manual fan operations          | Operates on selected heating speed and cycles off during ignition or burner start up sequence.                                                                 |
| - High limit control operation   | Automatic reset, ignition sequence restart. See Note 1.                                                                                                        |
| - Flame rollout switch operation | Manual reset, ignition sequence initiated after switch is manually reset. See Note 1.                                                                          |

*NOTE 1: After the fourth limit trip on a given call for heat there will be a 1 hour delay before the ignition sequence will restart. After either high limit switch or flame rollout switch actuation the inducer will operate for the 30 second post purge and the comfort air blower will operate for the selected off delay. If on Manual Fan operation, the comfort air blower will continue to operate.*

**SAFETY UNITS**

|                      |                        |
|----------------------|------------------------|
| High limit / Rollout | SPST in 24 Volt        |
| Pressure switch      | SPST, safe start check |

**COMFORT FAN CONTROL**

**Heating Speed Fan**

|                  |                                                                                 |
|------------------|---------------------------------------------------------------------------------|
| Normal operation |                                                                                 |
| - ON delay       | 30 seconds fixed. Timing starts when igniter de-energized                       |
| - OFF delay      | 3 selectable timings -120 seconds standard can be changed to 90 or 150 seconds. |
| Limit Operation  | ON when limit OPEN<br>OFF after OFF delay when limit CLOSSES                    |
| Flame Sense      | ON if flame is sensed <b>and</b> there is no call for heat.                     |

**Cooling Speed Fan**

|             |            |
|-------------|------------|
| - ON delay  | 7 seconds  |
| - OFF delay | 60 seconds |

**Manual Fan**

ON continuously on HEATING speed. When call for cool, the fan switches to COOLING speed. Then when thermostat satisfied, the fan switches back to HEATING speed after COOLING OFF delay.

**DIAGNOSTIC INDICATOR**

A red LED is provided to indicate system faults as follows:

- Steady ON - Control okay in standby, call for heat, cool or fan modes
- Steady OFF - Internal control fault or no power. Also check 3A fuse on control.
- 1 flash - Lockout due to failed ignition or flame dropouts
- 2 flashes - Pressure switch open with inducer on
- 3 flashes - Pressure switch is closed with inducer off
- 4 flashes - Limit switch is open
- 5 flashes - Flame detected with gas valve closed
- 6 flashes - Compressor output delayed from short cycle/staging timer

The flash rate is 0.25 seconds on, 0.25 seconds off with 2.0 seconds pause between flash codes.

The flash rate is 0.25 seconds on, 0.25 seconds off with 2.0 seconds pause between flash codes.

# START UP

---

These units require R-410A refrigerant & Polyol Ester oil.

## APPLICATION:

1. Use separate service and manufacturing equipment to avoid cross contamination of oil and refrigerants.
2. Use recovery equipment rated for R-410A refrigerant.
3. Use manifold gauges rated for R-410A (800 psi/ 250 psi low).
4. R-410A is a binary blend of HFC-32 and HFC-125.
5. R-410A is nearly azeotropic - similar to R-22 and R-12. Although nearly azeotropic, charge with liquid refrigerant.
6. R-410A operates at 40-70% higher pressure than R-22, and systems designed for R-22 cannot withstand this higher pressure.
7. R-410A has an ozone depletion potential of zero, but must be reclaimed due to its global warming potential.
8. R-410A compressors use Polyol Ester oil.
9. Polyol Ester oil is hygroscopic; it will rapidly absorb moisture and strongly hold this moisture in the oil.
10. A liquid line dryer must be used - even a deep vacuum will not separate moisture from the oil.
11. Limit atmospheric exposure to 15 minutes - **MAXIMUM**.
12. If compressor removal is necessary, always plug compressor immediately after removal. Purge with small amount of nitrogen when inserting plugs.

## IMPORTANT INSTALLER NOTE

For improved start-up performance, wash the indoor coil with a dishwasher detergent.

## HIGH & LOW PRESSURE SWITCH

All models covered by this Manual are supplied with a remote reset high pressure switch and low pressure switch. If tripped, this pressure switch may be reset by turning the thermostat off then back on again.

## THREE PHASE SCROLL COMPRESSOR START UP INFORMATION

Scroll compressors, like several other types of compressors, will only compress in one rotational direction. Direction of rotation is not an issue with single phase compressors since they will always start and run in the proper direction.

However, three phase compressors will rotate in either direction depending upon phasing of the power. Since there is a 50-50 chance of connecting power in such a way as to cause rotation in the reverse direction, verification of proper rotation must be made. All three phase units incorporate a phase monitor to ensure proper field wiring. See the “Phase Monitor” section in this manual.

Verification of **proper rotation** must be made any time a compressor is change or rewired. If improper rotation is corrected at this time there will be no negative impact on the durability of the compressor. However, reverse operation for over one hour may have a negative impact on the bearing due to oil pump out.

*NOTE: If compressor is allowed to run in reverse rotation for several minutes, the compressor's internal protector will trip.*

All three phase ZPS compressors are wired identically internally. As a result, once the correct phasing is determined for a specific system or installation, connecting properly phased power leads to the same Fusite terminal should maintain proper rotation direction.

Verification of proper rotation direction is made by observing that suction pressure drops and discharge pressure rises when the compressor is energized. Reverse rotation also results in an elevated sound level over that with correct rotations, as well as, substantially reduced current draw compared to tabulated values.

The direction of rotation of the compressor may be changed by reversing any two line connections to the unit.

*See “Phase Monitor”, Page 33.*

# Troubleshooting

## COMPRESSOR SOLENOID

(See Sequence of Operation on Page 37 for function.)

A nominal 24-volt direct current coil activates the internal compressor solenoid. The input control circuit voltage must be 18 to 28 volt ac. The coil power requirement is 20 VA. The external electrical connection is made with a molded plug assembly. This plug contains a full wave rectifier to supply direct current to the unloader coil.

**Compressor Solenoid Test Procedure** If it is suspected that the unloader is not working, the following methods may be used to verify operation.

1. Operate the system and measure compressor amperage. Cycle the compressor solenoid on and off at ten-second intervals. The compressor amperage should go up or down at least 25 percent.
2. If step one does not give the expected results, shut unit off. Apply 18 to 28 volt ac to the solenoid molded plug leads and listen for a click as the solenoid pulls in. Remove power and listen for another click as the solenoid returns to its original position.
3. If clicks can't be heard, shut off power and remove the control circuit molded plug from the compressor and measure the solenoid coil resistance. The resistance should be 32 to 60 ohms depending on compressor temperature.
4. Next, check the molded plug.

**Voltage check:** Apply control voltage to the plug wires (18 to 28 volt ac). The measured **dc** voltage at the female connectors in the plug should be around 15 to 27 vdc.

**Resistance check:** Measure the resistance from the end of one molded plug lead to either of the two female connectors in the plug. One of the connectors should read close to zero ohms, while the other should read infinity. Repeat with other wire. The same female connector as before should read zero, while the other connector again reads infinity. Reverse polarity on the ohmmeter leads and repeat. The female connector that read infinity previously should now read close to zero ohms.

Replace plug if either of these test methods does not show the desired results.

## FAN BLADE SETTING DIMENSIONS

Shown in the drawing below are the correct fan blade setting dimensions for proper air delivery across the outdoor coil. See Figure below.

Any service work requiring removal or adjustment in the fan and/or motor area will require that the dimensions below be checked and blade adjusted in or out on the motor shaft accordingly. See Table 11.

**FIGURE 18**  
**FAN BLADE SETTING**




**TABLE 11**  
**FAN BLADE DIMENSIONS**

| Model                   | Dimension A |
|-------------------------|-------------|
| WG3S2<br>WG4S2<br>WG5S2 | 1.75"       |

## REMOVAL OF FAN SHROUD

1. Disconnect all power to unit.
2. Remove the screws holding both grills – one on each side of unit – and remove grills.
3. Remove screws holding fan shroud to condenser and bottom – (9) screws.
4. Unwire condenser fan motor.
5. Slide complete motor, fan blade, and shroud assembly out the left side of the unit.
6. Service motor/fan as needed.
7. Reverse steps to reinstall.

# Troubleshooting ECM™ Motors

## CAUTION:

Disconnect power from unit before removing or replacing connectors, or servicing motor. To avoid electric shock from the motor's capacitors, disconnect power and wait at least 5 minutes before opening motor.

## Symptom

**Motor rocks slightly when starting**

**Motor won't start**  
• No movement

• Motor rocks, but won't start

**Motor oscillates up load & down while being tested off of blower**

**Motor starts, but runs erratically**  
• Varies up and down or intermittent

• "Hunts" or "puffs" at high CFM (speed)

• Stays at low CFM despite system call for cool or heat CFM

• Stays at high CFM

• Blower won't shut off

**Excessive noise**

• Air noise

## Cause/Procedure

• This is normal start-up for ECM

• Check blower turns by hand  
• Check power at motor  
• Check low voltage (24 Vac R to C) at motor  
• Check low voltage connections (G, Y, W, R, C) at motor  
• Check for unseated pins in connectors on motor harness  
• Test with a temporary jumper between R - G  
• Check motor for tight shaft  
• Perform motor/control replacement check  
• **Perform Moisture Check**

• Check for loose or compliant motor mount  
• Make sure blower wheel is tight on shaft  
• Perform motor/control replacement check

• It is normal for motor to oscillate with no on shaft

• Check line voltage for variation or "sag"  
• Check low voltage connections (G, Y, W, R, C) at motor, unseated pins in motor harness connectors  
• Check "Bk" for erratic CFM command (in variable-speed applications)  
• Check out system controls, Thermostat  
• **Perform Moisture Check**

• Does removing panel or filter reduce "puffing"?  
- Reduce restriction  
- Reduce max airflow

• Check low voltage (Thermostat) wires and connections  
• Verify fan is not in delay mode; wait until delay complete  
• "R" missing/not connected at motor  
• Perform motor/control replacement check

• "R" missing/not connected at motor  
• Is fan in delay mode? - wait until delay time complete  
• Perform motor/control replacement check

• Current leakage from controls into G, Y or W? Check for Triac switched thermostat or solid-state relay

• Determine if it's air noise, cabinet, duct or motor noise; interview customer, if necessary  
• High static creating high blower speed?  
- Is airflow set properly?  
- Does removing filter cause blower to slow down? Check filter  
- Use low-pressure drop filter  
- Check/correct duct restrictions

## Symptom

• Noisy blower or cabinet

• "Hunts" or "puffs" at high CFM (speed)

## Evidence of Moisture

• Motor failure or **Check** malfunction has occurred and moisture is present

• Evidence of moisture present inside air mover

## Do

• Check out motor, controls, wiring and connections thoroughly before replacing motor  
• Orient connectors down so water can't get in  
- Install "drip loops"  
• Use authorized motor and model #'s for replacement  
• Keep static pressure to a minimum:  
- Recommend high efficiency, low static filters  
- Recommend keeping filters clean.  
- Design ductwork for min. static, max. comfort  
- Look for and recommend ductwork improvement, where necessary

• Size the equipment wisely

• Check orientation before inserting motor connectors

## Moisture Check

• Connectors are oriented "down" (or as recommended by equipment manufacturer)  
• Arrange harness with "drip loop" under motor  
• Is condensate drain plugged?  
• Check for low airflow (too much latent capacity)  
• Check for undercharged condition  
• Check and plug leaks in return ducts, cabinet

## Comfort Check

• Check proper airflow settings  
• Low static pressure for lowest noise  
• Set low continuous-fan CFM  
• Use humidistat and 2-speed cooling units  
• Use zoning controls designed for ECM that regulate CFM  
• Thermostat in bad location?

## Cause/Procedure

• Check for loose blower housing, panels, etc.  
• High static creating high blower speed?  
- Check for air whistling through seams in ducts, cabinets or panels  
- Check for cabinet/duct deformation

• Does removing panel or filter reduce "puffing"?  
- Reduce restriction  
- Reduce max. airflow

• Replace motor and **Perform Moisture**

• **Perform Moisture Check**

## Don't

• Automatically assume the motor is bad.  
• Locate connectors above 7 and 4 o'clock positions  
• Replace one motor or control model # with another (unless an authorized replacement)  
• Use high pressure drop filters some have ½" H2O drop!  
• Use restricted returns  
• Oversize system, then compensate with low airflow  
• Plug in power connector backwards  
• Force plugs

# Troubleshooting ECM™ Motors Cont'd.

## Replacing ECM Control Module

To replace the control module for the GE variable-speed indoor blower motor you need to take the following steps:

1. You **MUST** have the correct replacement module. The controls are factory programmed for specific operating modes. Even though they look alike, different modules may have completely different functionality.

**USING THE WRONG CONTROL MODULE VOIDS ALL PRODUCT WARRANTIES AND MAY PRODUCE UNEXPECTED RESULTS.**

2. Begin by removing AC power from the unit being serviced. **DO NOT WORK ON THE MOTOR WITH AC POWER APPLIED.** To avoid electric shock from the motor's capacitors, disconnect power and wait at least 5 minutes before opening motor.

3. It is not necessary to remove the motor from the blower assembly, nor the blower assembly from the unit. Unplug the two cable connectors to the motor control assembly. There are latches on each connector. **DO NOT PULL ON THE WIRES.** The plugs remove easily when properly released.

4. Locate the screws that retain to the motor control bracket to the sheet metal of the unit and remove them. Remove two (2) nuts that retain the control to the bracket and then remove two (2) nuts that retain sheet metal motor control end plate. Refer to Figure 19.

5. Disconnect the three (3) wires interior of the motor control by using your thumb and forefinger squeezing the latch tab and the opposite side of the connector plug, gently pulling the connector. **DO NOT PULL ON THE WIRES, GRIP THE PLUG ONLY.** Refer to Figure 19.

6. The control module is now completely detached from the motor. Verify with a standard ohmmeter that the resistance from each motor lead (in the motor plug just removed) to the motor shell is >100K ohms. Refer to Figure 20. (Measure to unpainted motor end plate.) If any motor lead fails this test, do not proceed to install the control module. **THE MOTOR IS DEFECTIVE AND MUST BE REPLACED.** Installing the new control module will cause it to fail also.

7. Verify that the replacement control is correct for your application. Refer to the manufacturer's authorized replacement list. **USING THE WRONG CONTROL WILL RESULT IN IMPROPER OR NO BLOWER OPERATION.** Orient the control module so that the 3-wire motor plug can be inserted into the socket in the control. Carefully insert the plug and press it into the socket until it latches. **A SLIGHT CLICK WILL BE HEARD WHEN PROPERLY INSERTED.**

8. Reverse the steps #5, 4, 3 to reconnect the motor control to the motor wires, securing the motor control cover plate, mounting the control to the bracket, and mounting the motor control bracket back into the unit. **MAKE SURE THE ORIENTATION YOU SELECT FOR REPLACING THE CONTROL ASSURES THE CONTROL'S CABLE CONNECTORS WILL BE LOCATED DOWNWARD IN THE APPLICATION SO THAT WATER CANNOT RUN DOWN THE CABLES AND INTO THE CONTROL. DO NOT OVERTIGHTEN THE BOLTS.**


9. Plug the 16-pin control plug into the motor. The plug is keyed. Make sure the connector is properly seated and latched.

10. Plug the 5-pin power connector into the motor. Even though the plug is keyed, **OBSERVE THE PROPER ORIENTATION. DO NOT FORCE THE CONNECTOR.** It plugs in very easily when properly oriented. **REVERSING THIS PLUG WILL CAUSE IMMEDIATE FAILURE OF THE CONTROL MODULE.**

11. Final installation check. Make sure the motor is installed as follows:

- Motor connectors should be oriented between the 4 o'clock and 8 o'clock positions when the control is positioned in its final location and orientation.
- Add a drip loop to the cables so that water cannot enter the motor by draining down the cables. Refer to Figure 21.

The installation is now complete. Reapply the AC power to the HVAC equipment and verify that the new motor control module is working properly. Follow the manufacturer's procedures for disposition of the old control module.



### 33. PRESSURE SERVICE PORTS

High and low pressure service ports are installed on all units so that the system operating pressures can be observed. Table 12 outlines expected pressures at various indoor and outdoor temperatures.

**TABLE 12**  
**COOLING PRESSURE (ALL TEMPERATURES °F)**

| HIGH CAPACITY COOLING |                        |                       | AIR TEMPERATURE ENTERING OUTDOOR COIL DEGREE F |            |            |            |            |            |            |            |            |            |            |            |            |            |
|-----------------------|------------------------|-----------------------|------------------------------------------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|------------|
| MODEL                 | RETURN AIR TEMPERATURE | PRESSURE              | 50°F                                           | 55°F       | 60°F       | 65°F       | 70°F       | 75°F       | 80°F       | 85°F       | 90°F       | 95°F       | 100°F      | 105°F      | 110°F      | 115°F      |
| WG3S2                 | 75° DB<br>62° WB       | LOW SIDE<br>HIGH SIDE | 112<br>195                                     | 115<br>214 | 119<br>233 | 122<br>253 | 126<br>272 | 129<br>291 | 131<br>314 | 132<br>337 | 134<br>360 | 135<br>383 | 136<br>409 | 138<br>435 | 139<br>461 | 140<br>487 |
|                       | 80° DB<br>67° WB       | LOW SIDE<br>HIGH SIDE | 124<br>201                                     | 127<br>220 | 131<br>239 | 134<br>259 | 138<br>278 | 139<br>297 | 140<br>319 | 140<br>341 | 141<br>363 | 141<br>389 | 148<br>413 | 149<br>440 | 151<br>468 | 152<br>495 |
|                       | 85° DB<br>72° WB       | LOW SIDE<br>HIGH SIDE | 135<br>205                                     | 138<br>224 | 142<br>243 | 145<br>263 | 149<br>282 | 152<br>301 | 154<br>326 | 156<br>350 | 157<br>375 | 159<br>399 | 161<br>425 | 162<br>451 | 164<br>476 | 165<br>502 |
| WG4S2                 | 75° DB<br>62° WB       | LOW SIDE<br>HIGH SIDE | 117<br>197                                     | 119<br>216 | 121<br>235 | 123<br>255 | 125<br>274 | 127<br>293 | 128<br>316 | 130<br>339 | 131<br>361 | 132<br>383 | 133<br>410 | 135<br>438 | 136<br>466 | 137<br>494 |
|                       | 80° DB<br>67° WB       | LOW SIDE<br>HIGH SIDE | 127<br>201                                     | 129<br>220 | 131<br>239 | 134<br>259 | 136<br>278 | 138<br>298 | 138<br>318 | 139<br>341 | 139<br>364 | 145<br>381 | 145<br>415 | 146<br>443 | 146<br>471 | 149<br>500 |
|                       | 85° DB<br>72° WB       | LOW SIDE<br>HIGH SIDE | 141<br>203                                     | 143<br>223 | 145<br>243 | 148<br>263 | 150<br>283 | 152<br>303 | 152<br>326 | 153<br>349 | 153<br>372 | 154<br>396 | 156<br>422 | 158<br>449 | 160<br>478 | 162<br>508 |
| WG5S2                 | 75° DB<br>62° WB       | LOW SIDE<br>HIGH SIDE | 118<br>199                                     | 119<br>217 | 120<br>236 | 122<br>260 | 123<br>285 | 125<br>309 | 126<br>333 | 128<br>357 | 129<br>381 | 130<br>405 | 132<br>432 | 133<br>460 | 135<br>487 | 136<br>514 |
|                       | 80° DB<br>67° WB       | LOW SIDE<br>HIGH SIDE | 129<br>205                                     | 130<br>224 | 131<br>247 | 131<br>270 | 132<br>292 | 132<br>315 | 134<br>339 | 137<br>363 | 139<br>387 | 143<br>394 | 143<br>438 | 145<br>465 | 146<br>492 | 148<br>519 |
|                       | 85° DB<br>72° WB       | LOW SIDE<br>HIGH SIDE | 137<br>216                                     | 139<br>237 | 140<br>258 | 141<br>279 | 142<br>300 | 143<br>321 | 146<br>346 | 148<br>370 | 151<br>395 | 153<br>419 | 155<br>447 | 157<br>474 | 158<br>502 | 160<br>529 |

| LOW CAPACITY COOLING |                        |           | AIR TEMPERATURE ENTERING OUTDOOR COIL DEGREE F |      |      |      |      |      |      |      |      |      |       |       |       |       |
|----------------------|------------------------|-----------|------------------------------------------------|------|------|------|------|------|------|------|------|------|-------|-------|-------|-------|
| MODEL                | RETURN AIR TEMPERATURE | PRESSURE  | 50°F                                           | 55°F | 60°F | 65°F | 70°F | 75°F | 80°F | 85°F | 90°F | 95°F | 100°F | 105°F | 110°F | 115°F |
| WG3S2                | 75° DB                 | LOW SIDE  | 126                                            | 127  | 129  | 130  | 132  | 133  | 135  | 136  | 138  | 139  | 141   | 144   | 146   | 148   |
|                      | 62° WB                 | HIGH SIDE | 181                                            | 198  | 215  | 233  | 250  | 267  | 289  | 310  | 332  | 353  | 378   | 404   | 429   | 454   |
|                      | 80° DB                 | LOW SIDE  | 134                                            | 134  | 135  | 135  | 136  | 136  | 137  | 137  | 138  | 138  | 140   | 142   | 144   | 146   |
|                      | 67° WB                 | HIGH SIDE | 184                                            | 201  | 218  | 236  | 253  | 270  | 291  | 312  | 333  | 358  | 380   | 406   | 432   | 458   |
|                      | 85° DB                 | LOW SIDE  | 153                                            | 154  | 155  | 156  | 157  | 158  | 160  | 162  | 163  | 165  | 167   | 168   | 170   | 171   |
|                      | 72° WB                 | HIGH SIDE | 190                                            | 207  | 224  | 241  | 258  | 275  | 297  | 318  | 340  | 361  | 387   | 413   | 438   | 464   |
| WG4S2                | 75° DB                 | LOW SIDE  | 122                                            | 124  | 125  | 127  | 129  | 131  | 131  | 132  | 133  | 134  | 135   | 137   | 139   | 141   |
|                      | 62° WB                 | HIGH SIDE | 184                                            | 201  | 218  | 236  | 254  | 272  | 291  | 312  | 335  | 359  | 381   | 407   | 435   | 463   |
|                      | 80° DB                 | LOW SIDE  | 132                                            | 134  | 136  | 138  | 140  | 142  | 145  | 146  | 147  | 149  | 149   | 150   | 151   | 152   |
|                      | 67° WB                 | HIGH SIDE | 185                                            | 203  | 221  | 239  | 257  | 275  | 298  | 317  | 339  | 354  | 384   | 410   | 438   | 467   |
|                      | 85° DB                 | LOW SIDE  | 145                                            | 147  | 149  | 152  | 154  | 156  | 156  | 157  | 158  | 159  | 161   | 163   | 164   | 165   |
|                      | 72° WB                 | HIGH SIDE | 187                                            | 205  | 223  | 241  | 259  | 278  | 397  | 319  | 343  | 369  | 390   | 415   | 443   | 472   |
| WG5S2                | 75° DB                 | LOW SIDE  | 123                                            | 125  | 127  | 129  | 131  | 133  | 134  | 135  | 136  | 137  | 139   | 141   | 143   | 145   |
|                      | 62° WB                 | HIGH SIDE | 187                                            | 207  | 226  | 245  | 263  | 282  | 305  | 328  | 350  | 373  | 399   | 425   | 451   | 477   |
|                      | 80° DB                 | LOW SIDE  | 134                                            | 136  | 138  | 139  | 141  | 143  | 144  | 145  | 146  | 148  | 153   | 155   | 156   | 158   |
|                      | 67° WB                 | HIGH SIDE | 192                                            | 211  | 230  | 248  | 267  | 286  | 308  | 331  | 353  | 367  | 402   | 429   | 456   | 483   |
|                      | 85° DB                 | LOW SIDE  | 146                                            | 148  | 149  | 151  | 152  | 154  | 156  | 159  | 161  | 163  | 165   | 166   | 168   | 169   |
|                      | 72° WB                 | HIGH SIDE | 200                                            | 217  | 235  | 252  | 270  | 287  | 311  | 335  | 358  | 382  | 408   | 434   | 460   | 486   |

Low side pressure ± 4 PSIG  
High side pressure ± 10 PSIG

# R-410A

## 34. REFRIGERANT CHARGE

This unit was charged at the factory with the quantity of refrigerant listed on the serial plate. AHRI capacity and efficiency ratings were determined by testing with this refrigerant charge quantity.

The pressure tables (page 45) show nominal pressures for the units. Since many installation specific situations can affect the pressure readings, this information should only be used by certified technicians as a guide for evaluating proper system performance. They shall not be used to adjust charge. If charge is in doubt, reclaim, evacuate and recharge the unit to the serial plate charge.

## 35. LOW-NOX BURNER ASSEMBLY “N” SUFFIX MODELS ONLY – U.S. INSTALLATIONS ONLY


### NATURAL GAS MODELS ONLY

Model numbers designated with an “N” are designed for low NOx emissions which comply with all California Air Quality Management District regulations for nitrogen oxide emission levels. Refer to Figure below for NOx insert information.

### **\*\* IMPORTANT \*\***

For propane (LP) conversions the NOx reduction screen inserts shown below must be removed. This is accomplished by removing the burner box assembly and removing the NOx screens. Reassemble unit properly before firing. Failure to remove the NOx screens can result in improper operation and malfunction of the burner system.

**FIGURE 22  
LOW NOX INSERT**




MIS-1481

# INDEX

## WIRING DIAGRAMS and LADDER DIAGRAMS

| Model No.    | Heating Input | Input Power  | Wiring Diagram | Ladder Diagram |
|--------------|---------------|--------------|----------------|----------------|
| <b>WG3S2</b> | 50,000        | 208/230/60/1 | 4085-154A      | 4085-155       |
|              | 75,000        |              | 4085-156A      | 4085-157       |
|              | 100,000       |              | 4085-154A      | 4085-155       |
|              | 125,000       |              | 4085-156A      | 4085-157       |
| <b>WG3S2</b> | 50,000        | 208/230/60/3 | 4085-254A      | 4085-269       |
|              | 75,000        |              | 4085-255A      | 4085-270       |
|              | 100,000       |              | 4085-254A      | 4085-269       |
|              | 125,000       |              | 4085-255A      | 4085-270       |
| <b>WG3S2</b> | 50,000        | 460/60/3     | 4085-377A      | 4085-392       |
|              | 75,000        |              | 4085-378A      | 4085-393       |
|              | 100,000       |              | 4085-377A      | 4085-392       |
|              | 125,000       |              | 4085-378A      | 4085-393       |
| <b>WG4S2</b> | 50,000        | 208/230/60/1 | 4085-154A      | 4085-155       |
|              | 75,000        |              | 4085-156A      | 4085-157       |
|              | 100,000       |              | 4085-154A      | 4085-155       |
|              | 125,000       |              | 4085-156A      | 4085-157       |
| <b>WG4S2</b> | 50,000        | 208/230/60/3 | 4085-254A      | 4085-269       |
|              | 75,000        |              | 4085-255A      | 4085-270       |
|              | 100,000       |              | 4085-254A      | 4085-269       |
|              | 125,000       |              | 4085-255A      | 4085-270       |
| <b>WG4S2</b> | 50,000        | 460/60/3     | 4085-377A      | 4085-392       |
|              | 75,000        |              | 4085-378A      | 4085-393       |
|              | 100,000       |              | 4085-377A      | 4085-392       |
|              | 125,000       |              | 4085-378A      | 4085-393       |
| <b>WG5S2</b> | 50,000        | 208/230/60/1 | 4085-154A      | 4085-155       |
|              | 75,000        |              | 4085-156A      | 4085-157       |
|              | 100,000       |              | 4085-154A      | 4085-155       |
|              | 125,000       |              | 4085-156A      | 4085-157       |
| <b>WG5S2</b> | 50,000        | 208/230/60/3 | 4085-254A      | 4085-269       |
|              | 75,000        |              | 4085-255A      | 4085-270       |
|              | 100,000       |              | 4085-254A      | 4085-269       |
|              | 125,000       |              | 4085-255A      | 4085-270       |
| <b>WG5S2</b> | 50,000        | 460/60/3     | 4085-377A      | 4085-392       |
|              | 75,000        |              | 4085-378A      | 4085-393       |
|              | 100,000       |              | 4085-377A      | 4085-392       |
|              | 125,000       |              | 4085-378A      | 4085-393       |



| Model   | C. Breaker | Capacitor |
|---------|------------|-----------|
| WG3S2-A | 40A        | 40+10/370 |
| WG4S2-A | 45A        | 30+10/370 |
| WG5S2-A | 60A        | 40+10/440 |

USE COPPER CONDUCTORS  
SUITABLE FOR AT LEAST 75° C

Wire Identification numbers  
for Bard use only.


|              | Factory | Field | Optional |
|--------------|---------|-------|----------|
| High Voltage | ---     | ---   | ---      |
| Low Voltage  | ---     | ---   | ---      |

WIRES CONNECT  
IF OPTION  
NOT USED

IF ANY ORIGINAL WIRE AS SUPPLIED WITH THE APPLIANCE MUST BE  
REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A  
TEMPERATURE RATING OF AT LEAST 105° C EXCEPT THE IGNITION CABLE  
WHICH IS 250° C HIGH VOLTAGE CABLE




## WG3S2-A, WG4S2-A, WG5S2-A 208/230/60/1



|              | Factory | Optional |                                                                                                                               |
|--------------|---------|----------|-------------------------------------------------------------------------------------------------------------------------------|
| High Voltage |         | ---      | <br>Wires Connect<br>if Option Not<br>Used |
| Low Voltage  |         | ---      |                                                                                                                               |



WG3S2-A, WG4S2-A, WG5S2-A 208/230/60/1



| Model   | C. Breaker | Capacitor |
|---------|------------|-----------|
| WG3S2-A | 40A        | 40+10/370 |
| WG4S2-A | 45A        | 30+10/370 |
| WG5S2-A | 60A        | 40+10/440 |

USE COPPER CONDUCTORS  
SUITABLE FOR AT LEAST 75° C


Wire Identification numbers  
for Bard use only.

|              | Factory | Field | Optional |
|--------------|---------|-------|----------|
| High Voltage | ---     | ---   | ---      |
| Low Voltage  | ---     | ---   | ---      |

WIRES CONNECT  
IF OPTION  
NOT USED




WG3S2-A, WG4S2-A, WG5S2-A 208/230/60/1



|              | Factory | Optional | <br>Wires Connect<br>if Option Not<br>Used |
|--------------|---------|----------|-------------------------------------------------------------------------------------------------------------------------------|
| High Voltage | _____   | -----    |                                                                                                                               |
| Low Voltage  | _____   | -----    |                                                                                                                               |



**WG3S2-A, WG4S2-A, WG5S2-A 208/230/60/1**



| Model   | C. Breaker | Capacitor |
|---------|------------|-----------|
| WG3S2-B | 30A        | 10/370    |
| WG4S2-B | 40A        | 10/370    |
| WG5S2-B | 40A        | 10/370    |

USE COPPER CONDUCTORS  
SUITABLE FOR AT LEAST 75° C

IF ANY ORIGINAL WIRE AS SUPPLIED WITH THE APPLIANCE MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A TEMPERATURE RATING OF AT LEAST 105° C EXCEPT THE IGNITION CABLE WHICH IS 250° C HIGH VOLTAGE CABLE


Wire Identification numbers for Bard use only.

|              | Factory | Field | Optional |
|--------------|---------|-------|----------|
| High Voltage |         |       |          |
| Low Voltage  |         |       |          |

WIRES CONNECT  
IF OPTION  
NOT USED




## WG3S2-B, WG4S2-B, WG5S2-B 208/230/60/3



|              | Factory | Optional |                                      |
|--------------|---------|----------|--------------------------------------|
| High Voltage | ---     | ---      | <br>Wires Connect if Option Not Used |
| Low Voltage  | ---     | ---      |                                      |



WG3S2-B, WG4S2-B, WG5S2-B 208/230/60/3



| Model   | C. Breaker | Capacitor |
|---------|------------|-----------|
| WG3S2-B | 30A        | 10/370    |
| WG4S2-B | 40A        | 10/370    |
| WG5S2-B | 40A        | 10/370    |

USE COPPER CONDUCTORS  
SUITABLE FOR AT LEAST 75° C


IF ANY ORIGINAL WIRE AS SUPPLIED WITH THE APPLIANCE MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A TEMPERATURE RATING OF AT LEAST 105° C EXCEPT THE IGNITION CABLE WHICH IS 250°C HIGH VOLTAGE CABLE

|              | Factory | Field | Optional |
|--------------|---------|-------|----------|
| High Voltage |         |       |          |
| Low Voltage  |         |       |          |

WIRES CONNECT  
IF OPTION  
NOT USED

**Bard**  
Bard Mfg. Co.  
Bryan, Ohio  
4085-255 A

## WG3S2-B, WG4S2-B, WG5S2-B 208/230/60/3




|              | Factory | Optional |
|--------------|---------|----------|
| High Voltage |         | ---      |
| Low Voltage  |         | ---      |


 Wires Connect if Option Not Used



WG3S2-B, WG4S2-B, WG5S2-B 208/230/60/3




## WG3S2-C, WG4S2-C, WG5S2-C 460/60/3




|              | Factory | Optional |                                                                                                                               |
|--------------|---------|----------|-------------------------------------------------------------------------------------------------------------------------------|
| High Voltage | ---     | ---      | <br>Wires Connect<br>if Option Not<br>Used |
| Low Voltage  | ---     | ---      |                                                                                                                               |



WG3S2-C, WG4S2-C, WG5S2-C 460/60/3



## WG3S2-C, WG4S2-C, WG5S2-C 460/60/3



|              | Factory | Optional |                                                                                                                               |
|--------------|---------|----------|-------------------------------------------------------------------------------------------------------------------------------|
| High Voltage | ---     | ---      | <br>Wires Connect<br>if Option Not<br>Used |
| Low Voltage  | ---     | ---      |                                                                                                                               |



WG3S2-C, WG4S2-C, WG5S2-C 460/60/3