


For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com



NOTE: JUMPER PLUG MUST BE INSTALLED WHEN NO VENT OPTION IS INSTALLED

A → **A**
 Same Letter Designated Wires Connect if Option Not Used
 A No Control Option
 B & *C* Only LAC Option

WARNING
 USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
 *ELECTRICAL SHOCK HAZARD
 *DISCONNECT POWER BEFORE SERVICING.

	Factory	Field	Optional
High Voltage			
Low Voltage			

Wire Identification numbers for Bard use only.
4096-196