

---

# SUPPLEMENTAL INSTRUCTIONS

---

## CMA-36 BG1000 Power Supply Kit

---

This power supply kit offers an alternate method for powering the Bard Guard Anti-Theft System, providing power to the BG1000-100 controller through a 110V/120V wall outlet. See the latest version of Bard Guard Installation Instructions manual 2100-672 for complete information on installing and operating the Bard Guard Anti-Theft System.

The CMA-36 BG1000 Power Supply kit consists of:

- 910-2045 Power Supply
- 3000-1590 68" 3 Prong Plug Cable
- 7960-802 Supplemental Instructions


Tools needed for the installation:

- Small flat head screwdriver for securing wire in terminal blocks

### INSTALLATION

1. Connect the 68" 3 prong cable and power supply together.
2. Open BG1000 controller box and locate controller terminal block (see Figure 1).
3. Insert end of black/white wire of power supply cable into terminal 12 and end of black wire into terminal 13. Use screwdriver to tighten terminals on the wires.
4. Insert 3 prong plug into 110V-120V outlet.
5. Observe red LED indicator light on front of BG1000 controller box. When lit, this light indicates that the controller is powered and alarmed (alarm is set). If the red LED is not lit, check wire connections to confirm the black/white wire is properly connected to terminal 12. If wired improperly, the Bard Guard will not function.

FIGURE 1  
BG1000 Terminal Block



Bard Manufacturing Company, Inc.  
Bryan, Ohio 43506  
www.bardhvac.com

Manual: 7960-802  
Supersedes: **NEW**  
Date: 1-16-18