




**Economizer Wiring Diagram
"E" Enthalpy Outdoor
Sensor**

4056-227 B