




△ SET ADJUST HEAT ANTICIPATOR AT .45A

WATERSOURCE HEATPUMP WITHOUT  
OPTIONAL DUCT HEATER

|              | FACTORY<br>WIRING | FIELD<br>WIRING |
|--------------|-------------------|-----------------|
| LOW VOLTAGE  | _____             | -----           |
| HIGH VOLTAGE | —————             | -----           |