




NOTE:
BARD 8403-066 CONTROLLER
MUST BE USED WITH THESE
UNITS. A THERMOSTAT WILL NOT WORK.

Wires Connect if Option Not Used	Factory		
	Field		
	Optional		
High Voltage			
Low Voltage			

WARNING

USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75° C.

DANGER

ELECTRICAL SHOCK HAZARD
*DISCONNECT POWER BEFORE
SERVICING.