





COMPONENT CODE			
CB1	CIRCUIT BREAKER #1	PL1	ACCESSORY PLUG #1
CB2	CIRCUIT BREAKER #2	PL2	ACCESSORY PLUG #2
CC	COMPRESSOR CONTACTOR	PL3	ACCESSORY PLUG #3
CCM	COMPRESSOR CONTROL MODULE	PL4	ACCESSORY PLUG #4
COMP	COMPRESSOR	PL5	ACCESSORY PLUG #5
CRC	COMPRESSOR RUN CAPACITOR	PL6	ACCESSORY PLUG #6
DFC	DEFROST CONTROL	PL7	ACCESSORY PLUG #7
DFS	DEFROST SENSOR	PL8	ACCESSORY PLUG #8
FB	FUSE BLOCK	PL9	ACCESSORY PLUG #9
GND	GROUND	PL10	ACCESSORY PLUG #10
HC1	HEATER CONTACTOR #1	PL11	ACCESSORY PLUG #11
HC2	HEATER CONTACTOR #2	PL12	ACCESSORY PLUG #12
HPC	HIGH PRESSURE CONTROL	PL13	ACCESSORY PLUG #13
HS1	HEAT STRIP #1	PL14	ACCESSORY PLUG #14
HS2	HEAT STRIP #2	PL15	ACCESSORY PLUG #15
IBM	INDOOR BLOWER MOTOR	PL16	ACCESSORY PLUG #16
LAC	LOW AMBIENT CONTROL	PL17	ACCESSORY PLUG #17
LPB	LOW PRESSURE BYPASS	PL18	ACCESSORY PLUG #18
LPC	LOW PRESSURE CONTROL	PL19	ACCESSORY PLUG #19
LS	LIMIT SWITCH	PL20	ACCESSORY PLUG #20
OFM	OUTDOOR FAN MOTOR	PL21	ACCESSORY PLUG #21
OMR	OUTDOOR MOTOR RELAY	PL22	ACCESSORY PLUG #22
P1	ACCESSORY PLUG #1	PL23	ACCESSORY PLUG #23
P2	ACCESSORY PLUG #2	PL24	ACCESSORY PLUG #24
P3	ACCESSORY PLUG #3	PL25	ACCESSORY PLUG #25
PL1	PRESSURE LOCKOUT INDICATOR	PL26	ACCESSORY PLUG #26
PM	PHASE MONITOR	PL27	ACCESSORY PLUG #27
RV	REV. VALVE SOLINOID	PL28	ACCESSORY PLUG #28
SR	STAGING RELAY	PL29	ACCESSORY PLUG #29
T1	TRANSFORMER #1	PL30	ACCESSORY PLUG #30
T2	TRANSFORMER #2	PL31	ACCESSORY PLUG #31
TB1	TERMINAL BLOCK #1	PL32	ACCESSORY PLUG #32
TB2	TERMINAL BLOCK #2	PL33	ACCESSORY PLUG #33
TB3	TERMINAL BLOCK #3	PL34	ACCESSORY PLUG #34
TB4	TERMINAL BLOCK #4	PL35	ACCESSORY PLUG #35
TB5	TERMINAL BLOCK #5	PL36	ACCESSORY PLUG #36
TB6	TERMINAL BLOCK #6	PL37	ACCESSORY PLUG #37
TB7	TERMINAL BLOCK #7	PL38	ACCESSORY PLUG #38
TWV	THREE WAY VALVE	PL39	ACCESSORY PLUG #39

Labeled wires connect if no options used.			
Move red wire to 208V tap for 208V operation			
Install jumper for high speed blower oper. on models 36, 42, 48, and 60			

Remove jumper when LAC is installed			
-------------------------------------	--	--	--

WIRING CODE			
	FACTORY STD.	FIELD	OPTIONAL
HIGH VOLTAGE			
LOW VOLTAGE			
ACCESSORY			

COLOR CODE			
BK	BLACK	PK	PINK
BL	BLUE	PR	PURPLE
BR	BROWN	R	RED
G	GREEN	T	TAN
GY	GRAY	Y	YELLOW
O	ORANGE		

4100-108 D