




For Vent Wiring or controller/thermostat connections, see literature packet or go to www.bardhvac.com

R Vent option only

1
2
3

Purple/Black
Blue/Black

Black
Red
Yellow

Compressor

Green
Blue
Yellow
Brown
Black

Low Ambient Control (opt.)

Hi Press. Control

Defrost Sensor

Low Press. Control

Reversing Valve

Outdoor Temp Switch (Opt.)

A → **A**
Same Letter Designated Wires Connect if Option Not Used
"A" & "C" No Control Option
"B" Only Freeze Stat

WARNING
USE COPPER CONDUCTORS ONLY SUITABLE FOR AT LEAST 75° C.

DANGER
*ELECTRICAL SHOCK HAZARD
*DISCONNECT POWER BEFORE SERVICING.

	Factory	Field	Optional
High Voltage			
Low Voltage			

Wire Identification numbers for Bard use only.

4100-127 D