





COMPONENT CODE

CB1	CIRCUIT BREAKER #1
CB2	CIRCUIT BREAKER #2
CC	COMPRESSOR CONTACTOR
COMP	COMPRESSOR
DFC	DEFROST CONTROL
DF1	DIRTY FILTER INDICATOR
DFS	DIRTY FILTER SWITCH
DS	DOOR SWITCH
EHR	EMERGENCY HEAT RELAY
END	GROUND
HC1	HEATER CONTACTOR #1
HC2	HEATER CONTACTOR #2
HPS	HIGH PRESSURE SWITCH
HS1	HEAT STRIP #1
HS2	HEAT STRIP #2
IBM	INDOOR BLOWER MOTOR
LAB	LOW AMBIENT BYPASS
LAC	LOW AMBIENT CONTROL
LPB	LOW PRESSURE BYPASS
LPS	LOW PRESSURE SWITCH
LS	LIMIT SWITCH
OFM	OUTDOOR FAN MOTOR
OMT	OUTDOOR MOTOR THERMOSTAT
P1	ACCESSORY PLUG #1
P2	ACCESSORY PLUG #2
P3	ACCESSORY PLUG #3
PL1	PRESSURE LOCKOUT INDICATOR
RV	REV. VALVE SOLINOID
T1	TRANSFORMER #1
T2	TRANSFORMER #2
TB1	TERMINAL BLOCK #1
TB2	TERMINAL BLOCK #2
TB3	TERMINAL BLOCK #3
TB4	TERMINAL BLOCK #4
OMR	OUTDOOR MOTOR RELAY
WL1	HIGH WATER LEVEL INDICATOR
WLR	HIGH WATER LEVEL RELAY
WLS	WATER LEVEL SWITCH

USE COPPER CONDUCTORS ONLY
SUITABLE FOR AT LEAST 75°C



LABELED WIRES CONNECT
IF NO OPTIONS USED.



MOVE RED WIRE TO 208 V
TAP FOR 208 V OPERATION



REMOVE JUMPER FOR LOW
SPEED BLOWER OPERATION

	FACTORY STD.	FIELD	OPTIONAL
HIGH VOLTAGE			
LOW VOLTAGE			
ACCESSORY			
BK - BLACK BN - BROWN R - RED O - ORANGE Y - YELLOW	G - GREEN BL - BLUE PR - PURPLE CY - GREY W - WHITE	T - TAN PK - PINK L - LAVENDER	

4100-300