





▲ Labeled wires connect if no options used. ▲ Remove jumper when CS2000 Energy Monitor is installed.

▲ Install jumper for hi speed blower oper. on models 36, 42, 48, and 60.

▲ Remove jumper when Low Amb. Bypass is installed.

WARNING
USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75° C.

DANGER
ELECTRICAL SHOCK HAZARD
DISCONNECT POWER BEFORE
SERVICING.

	Factory	Field	Optional
High Voltage			
Low Voltage			

Bard Mfg. Co.
Bryan, Ohio
4100-316 C