

 **WARNING**
USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75° C.

	Factory	Field	Optional
High Voltage		-----	-----
Low Voltage		-----	-----

- Labeled wires connect if no options used.
- Move Red wire to 208V tap for 208V operation.
- Install jumper for hi speed blower oper. on models 36, 42, 48, and 60.
- Remove jumper when Low Amb. Bypass is installed.

