







- A** **B** **C** **D** Labeled wires connect if no options used.
- E** Move Red wire to 208V tap for 208V operation.
- F** Install jumper for hi speed blower oper. on models 36, 42, 48, and 60.
- H** Remove jumper when Low Amb. Bypass is installed.
- J** Remove jumper when CS2000A Energy Monitor is installed.