




LT LIQUID TEMPERATURE
AFS AIR FLOW SWITCH
DFS DIRTY FILTER SWITCH
OATH OUTDOOR TEMP. AND HUMID. SENSOR
SP SUCTION PRESSURE TRANSDUCER
LP LIQUID PRESSURE TRANSDUCER
SAT SUPPLY AIR TEMPERATURE
RAT RETURN AIR TEMPERATURE
ST SUCTION TEMPERATURE
BS BLADE SWITCH
DFL DIRTY FILTER LIGHT
TB TERMINAL BLOCK
HPS HIGH PRESSURE SWITCH
CCH CRANKCASE HEATER
EEV ELECTRONIC EXPANSION VALVE

	Factory	Field	Optional
High Voltage		---	---
Low Voltage		---	---
D-10VDC	---		