




- AFS

CB

CCH

DS

DFS

DP

EEV

FDS

FS

HPALA

HPC

LLT

MAT

OATH

RAT

SAT

SP

ST

(R)

(C)

(L)

#
- AIR FLOW SWITCH

CIRCUIT BREAKER

CRANKCASE HEATER

DAMPER SWITCH

DIRTY FILTER SWITCH

DISCHARGE PRESSURE

ELECTRONIC EXPANSION VALVE

FAN DISABLE SWITCH

FREEZE SENSOR

HIGH PRESSURE ALARM

HIGH PRESSURE CONTROL

LIQUID LINE TEMPERATURE

MIXTURE AIR TEMPERATURE

OUTDOOR TEMP. AND HUMIDITY SENSOR

RETURN AIR TEMPERATURE

SUPPLY AIR TEMPERATURE

SUCTION PRESSURE

SUCTION TEMPERATURE

RELAY COIL

CONTACTOR COIL

TB= TERMINAL BLOCK

FILTER LIGHT

TERMINAL BLOCK (WITH NUMBER DESIGNATION)