




- AFS
CB
CCH
DS
DFS
DP
EEV
FDS
FS
HPALA
HPC
LLT
MAT
OATH
RAT
SAT
SP
ST
R
C
TB= TERMINAL BLOCK
L
- AIR FLOW SWITCH
CIRCUIT BREAKER
CRANKCASE HEATER
DAMPER SWITCH
DIRTY FILTER SWITCH
DISCHARGE PRESSURE
ELECTRONIC EXPANSION VALVE
FAN DISABLE SWITCH
FREEZE SENSOR
HIGH PRESSURE ALARM
HIGH PRESSURE CONTROL
LIQUID LINE TEMPERATURE
MIXTURE AIR TEMPERATURE
OUTDOOR TEMP. AND HUMIDITY SENSOR
RETURN AIR TEMPERATURE
SUPPLY AIR TEMPERATURE
SUCTION PRESSURE
SUCTION TEMPERATURE
RELAY COIL
CONTACTOR COIL
TB= TERMINAL BLOCK
FILTER LIGHT