575-3-60
575-3-50
Per Nameplate

0 off
1 on

Toggle Disconnect

Power Terminal Block

HC1 HC2

Transformer

Red Wire to 415V tap for 415V Operation

-24V com TB

24V TB

Comp Contactor 1

Compressor 1 With 2 Stage

Compressor 2

Comp Contactor 2

DAMPER TERMINAL BLOCK

Phase Monitor 1

To CC1

From CCM1

Phase Monitor 2

To CC2

From CCM2

Fuse Block 600v

Terminal Block 480v

TRANSFORMER
PRI. 575V / SEC. 480V

Blower Motor

Fan Motor

Two Conductor Shielded Cable
Note: Connect drain to motor side only.
Field Bus 1

ECONOMIZER UNIT ONLY

LEFT DAMPER White
EXHAUST DAMPER Brown/White
RIGHT DAMPER White

AFS1 DFS1

HPAL R1 HPAL R2

RAT SAT OATH

4-20mA

SP1 SP2 LPT 1 LPT 2

Dust Sensor

ST1 ST2

PS1 PS2

(Left) DS1 (Exhaust) DS2 (Right) DS3

FS1 FS2

LLT1 LLT2 MAT

3 µ Pc3

UNIT DISPLAY TERMINALS

DISPLAY PORT

Field Bus 2 Field Bus 1

Two Conductor Shielded Cable
Connect shield to terminal block

CCM 1 CCM 2

Comp Contactor Coil 1 Comp Contactor Coil 2

Phase Monitor Phase Monitor 2

HPALA 1 HPALA 2

Staging Solenoid Compressor

Heat Contactor Coil 1 Heat Contactor Coil 2

Filter Light

LPC BLUE

EEV2 EEV1

DIP SWITCH
SHADED REPRESENTS SWITCH LOCATION
Address Ext Baud Prot
On Off

13 C. pcoe

J6 BSM
Gnd Tx/Rx

Two Conductor Shielded Cable.
Field Bus 1 Connect shield to terminal block

AFS	AIR FLOW SWITCH
CB	CIRCUIT BREAKER
CCH	CRANKCASE HEATER
DS	DAMPER SWITCH
DFS	DIRTY FILTER SWITCH
LPT	LIQUID PRESSURE TRANSDUCER
EEV	ELECTRONIC EXPANSION VALVE
PS	PANEL SWITCH
FS	FREEZE SENSOR
HPALA	HIGH PRESSURE ALARM
HPC	HIGH PRESSURE CONTROL
LLT	LIQUID LINE TEMPERATURE
MAT	MIXTURE AIR TEMPERATURE
OATH	OUTDOOR TEMP. AND HUMIDITY SENSOR
RAT	RETURN AIR TEMPERATURE
SAT	SUPPLY AIR TEMPERATURE
SP	SUCTION PRESSURE
ST	SUCTION TEMPERATURE
(R)	RELAY COIL
(C)	CONTACTOR COIL
	TB= TERMINAL BLOCK
	FILTER LIGHT
##	TERMINAL BLOCK (*WITH NUMBER DESIGNATION*)

4212-707 A