
SPLIT AIR CONDITIONER

REPLACEMENT PARTS MANUAL

MODELS: HAC241-AD065
HAC301-AD065
HAC421-AD065
HAC601-AD065

General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

Contents

Description	Page
Functional and Cabinet Components	
♦ Exploded View	1
♦ Usage List	2
♦ Usage List	3

Important


- Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plates.



BARD MANUFACTURING COMPANY
Bryan, Ohio 43506
Since 1914...Moving ahead, just as planned.

Manual: 2110-015
Supersedes:
File:
Date: 06-08-01

FUNCTIONAL and CABINET COMPONENTS



FUNCTIONAL and CABINET COMPONENTS

Drawing No.	Part No.	Description	HAC241-AD065	HAC301-AD065	HAC421-AD065	HAC601-AD065
1	7051-018	Fan and Motor Mount Grille				X
1	4051-029	Fan and Motor Mount Grille	X	X	X	
2	8102-010	Motor -- Fan 230/208-60-1	X	X	X	
2	8104-010	Motor -- Fan 230/208-60-1				X
3	5151-036	Fan Blade				X
3	5151-048	Fan Blade	X	X	X	
4	S166-014	Fan Venturi				X
4	S166-015	Fan Venturi	X	X	X	
5	101-280-X	Right Side / Front		X	X	
5	101-284-X	Right Side / Front	X			
5	101-297-X	Right Side / Front				X
6	127-227	Base		X	X	
6	127-238	Base	X			
6	127-247	Base				X
7	5054-068	Condenser Coil		X		
7	5054-071	Condenser Coil	X			
7	5054-078	Condenser Coil				X
7	5054-083	Condenser Coil				
7	5054-066	Condenser Coil			X	X
8	107-150-X	Top		X	X	
8	107-154-X	Top	X			
8	107-160-X	Top				X
9	121-260-X	Partition	X	X	X	
9	121-280-X	Partition				X
10	8000-130	Compressor CR38K6-PFV				X
10	8000-179	Compressor H27A56QCBC				
10	8000-166	Compressor CR28K6-PFV-370		X		
10	8000-167	Compressor CR22K6-PFV-370	X			
10	8000-165	Compressor CR32K6-PFV			X	
11	5651-114	Base Valve 3/8" x 3/8"	X	X	X	X
12	5651-113	Base Valve 3/4" x 3/4"	X	X	X	
12	5651-119	Base Valve 7/8" x 7/8"				X
13	165-544-X	Wire Channel	X	X	X	X
14	101-279-X	Left Side	X	X	X	
14	101-298-X	Left Side				X
15	117-200	Control Panel	X	X	X	X
16	133-122	Control Panel Cover	X	X	X	X
17	141-205-X	Base Valve Support	X	X	X	X
18	165-543	Channel	2	2	2	2
Parts List Continued on Page 3						