

---

# REPLACEMENT PARTS MANUAL

# GROUND SOURCE HEATER PACKAGE

MODEL: EH3GSVA

---

## General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

## Contents

| <i>Description</i>    | <i>Page</i> |
|-----------------------|-------------|
| Functional Components |             |
| ♦ Exploded View ..... | 1           |
| ♦ Usage List .....    | 2           |

## Important

- Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plates.




BARD MANUFACTURING COMPANY  
Bryan, Ohio 43506  
*Since 1914...Moving ahead, just as planned.*

Manual: 2110-154B  
Supersedes: 2110-154A  
File: Tab 7  
Date: 09-19-03

---

## FUNCTIONAL COMPONENTS

---



MIS-1244

## FUNCTIONAL COMPONENTS

---

| Drawing<br>No. | Part No. | Description                    | EH3GSVA-A05C | EH3GSVA-A09C | EH3GSVA-A14C |
|----------------|----------|--------------------------------|--------------|--------------|--------------|
|                |          |                                |              |              |              |
| 1              | 116-223  | Heater Package Wrapper         | X            | X            | X            |
| 2              | 116-225  | Heater Package Front           | X            | X            | X            |
| 3              | 8604-092 | 4.5 KW Heat Strip 240V         | X            |              |              |
| 3              | 8604-093 | 9 KW Heat Strip 240V           |              | X            |              |
| 3              | 8604-114 | 14 KW Heat Strip 240V          |              |              | X            |
| 4              | 8402-056 | Limit Control L150-3.5         | 1            | 2            | 3            |
| 5              | 116-228  | Heater Package Control Panel   | X            | X            | X            |
| 6              | 8615-036 | Circuit Breaker                | X            |              | X            |
| 6              | 8615-040 | Circuit Breaker                |              | X            | X            |
| 7              | 8615-047 | Circuit Breaker Terminal Block |              |              | X            |
| 8              | 8201-057 | Time Delay Relay H30-75 C1-40  | X            |              | X            |
| 8              | 8201-058 | Time Delay Relay H1-30 C45-70  |              | X            | X            |
| NS             | 142-069  | Fill Plate                     | X            | X            |              |
| NS             | 4106-100 | Wiring Diagram                 | X            |              |              |
| NS             | 4106-110 | Wiring Diagram                 |              | X            |              |
| NS             | 4106-120 | Wiring Diagram                 |              |              | X            |