
Replacement Parts Manual

Packaged Air Conditioner and Heat Pump Heater Packages

MODEL: EH3PB
EH3PC

General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

Important

- Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plates.

Contents

Description	Page
Functional Components – A Series	
♦ Exploded View	1
♦ Usage List	2
Functional Components – B and C Series	
♦ Exploded View	3
♦ Usage List	4




Bard Manufacturing Company, Inc.
Bryan, Ohio 43506

Since 1914...Moving ahead, just as planned.

Manual: 2110-306A
File: Tab 12
Date: 09-04-98

FUNCTIONAL COMPONENTS – A SERIES




SEXP-093

FUNCTIONAL COMPONENTS – A SERIES

Drawing No.	Part No.	Description	EH3PB-A05	EH3PB-A08	EH3PB-A10	EH3PB-A15	EH3PC-A05	EH3PC-A10	EH3PC-A15
1	116-175	Heater Box Assembly	X	X	X	X	X	X	X
2	8604-089	Heat Strip 5 KW 240V	X				X		
2	8604-090	Heat Strip 8 KW 240V		X					
2	8604-095	Heat Strip 10 KW 240V			X			X	
2	8604-096	Heat Strip 15 KW 240V				X			X
3	136-091	Fill Plate	X	X	X		X	X	
3	136-253	Fill Plate				X			X
4	8402-091	Thermal Cutoff	1	2	2	3	1	2	3
5	8402-049	Limit Control	X	X	X				
5	8402-097	Limit Control				X			
5	8402-082	Limit Control					X		X
5	8402-012	Limit Control						X	
6	8401-006	Contactors	X	X	X	2	X	X	2
7	8201-008	Blower Relay	X	X	X	X	X	X	X
8	3000-1026	Wire Assembly	X	X	X	X	X	X	X
9	8614-017	Fuse Block				X			X
10	8607-013	Terminal Block	X	X	X		X	X	
11	116-176	Heater Box Plate	X	X	X	X	X	X	X
NS	132-131	Control Panel Cover	X	X	X		X	X	
NS	132-132	Control Panel Cover				X			X
NS	133-133	Fuse Cover				X			X
THE FOLLOWING PARTS CONTAINED IN THE PLASTIC BAG									
	8607-013	Terminal Block	X	X	X	X	X	X	X
	8611-006	Ground Terminal	X	X	X	X	X	X	X
	4067-111	Wiring Diagram	X				X		
	4067-122	Wiring Diagram		X	X			X	
	4067-131	Wiring Diagram				X			X

NS = Not Shown

FUNCTIONAL COMPONENTS – B, C SERIES



SEXP-094

FUNCTIONAL COMPONENTS – B, C SERIES

Drawing No.	Part No.	Description	EH3PB-B09	EH3PB-B15	EH3PB-C09	EH3PB-C15
1	116-175	Heater Box Assembly	X	X	X	X
2	8604-048	Heat Strip 9KW 240V	X	X		
2	8604-049	Heat Strip 6KW 240V		X		
2	8604-101	Heat Strip 9 KW 480V			X	
2	8604-100	Heat Strip 6 KW 480V			X	X
3	136-091	Fill Plate	X		X	
4	8402-091	Thermal Cutoff	2	4		
4	8402-095	Thermal Cutoff			2	4
5	8402-097	Limit Control		X		X
5	8402-049	Limit Control	X		X	
6	8401-006	Contactor	X	2		
6	8401-002	Contactor			X	2
7	116-176	Heater Box Plate	X	X	X	X
8	300-1026	Wire Assembly	X	X	X	X
9	8607-014	Terminal Block	X	X	X	X
10	8607-015	Phenolic Insulator			X	X
11	8201-008	Blower Relay	X	X		
11	8201-032	Blower Relay			X	X
NS	132-131	Control Panel Cover	X	X	X	X
THE FOLLOWING PARTS CONTAINED IN THE PLASTIC BAG						
	8607-014	Terminal Block	X	X	X	X
	8611-006	Ground Terminal	X	X	X	X
	8607-015	Phenolic Insulator			X	X
	4067-211	Wiring Diagram	X			
	4067-221	Wiring Diagram		X		
	4067-311	Wiring Diagram			X	
	4067-321	Wiring Diagram				X

NS = Not Shown