


⚠ DANGER

*ELECTRICAL SHOCK HAZARD
*DISCONNECT POWER BEFORE
SERVICING.

⚠ WARNING


USE COPPER CONDUCTORS
ONLY SUITABLE FOR AT LEAST
75° C.

Note: See Control Wiring Section of Installation Inst. for Wiring Energy Recovery to Unit



Component	Capacitor
Blower Motor	4/370
Cassette Motor	3/250

1 DISCONNECT ORANGE WIRE FROM
TERMINAL BLOCK AND CONNECT RED
WIRE FOR 208V OPERATION



Note: See Control Wiring Section of Installation Inst.
for Wiring Energy Recovery to Unit

4114-102 A