

Replacement Parts Manual

Wall Mounted Package Air Conditioner

Model: **WA602N**

General Notes

- Revised and/or additional pages may be issued from time to time.
- A complete and current manual consists of pages shown in the following contents section.

Important

- Contact the installing and/or local Bard distributor for all parts requirements. Make sure you have the complete model and serial number available from the unit rating plates.

Contents

Description	Page
Cabinet Components	
• Exploded View	1
• Usage List	2
Functional Components	
• Exploded View	3
• Usage List	4
Control Panel	
• Exploded View	5
• Usage List	6
Blower Assembly	
• Exploded View	7
• Usage List	7




BARD MANUFACTURING COMPANY
Bryan, Ohio 43506

Since 1974... Moving ahead, just as planned.


Manual: 2 110-434
File: 2150-004, Tab 16
Date: 01-18-99

CABINET COMPONENTS



SEXP-316

FUNCTIONAL COMPONENTS



SEXP-177

Drawing No.	Part No.	Description	
1	S127Y214	Lower Base	X
2	S500-262-* ①	Left Side	X
3	S500-261-* ①	Right Side	X
4	S508-155	Back	X
5	S506-142-* ①	Top	X
6	S514-077-* ①	Upper Front	X
7	S552-224-* ①	Service Door	X
8	118-031-* ①	Condenser Grille	X
9	118-032-* ①	Side Grille	2
10	S521X333	Condenser Partition	X
11	123-083	Drain Pan	X
12	121X216	Blower Partition	X
13	Control Panel Assembly	See Control Panel Assembly Drawing & Parts List	X
14	S133-114	Control Panel Cover (Inner)	X
15	S533-113-* ①	Control Panel Cover (Outer)	X
16	S153-218-* ①	Dicsonnect Access Door	X
17	125-024	Fan Shroud	X
18	113-140	Bottom Mounting Bracket	X
19	137-209	Fill	X
20	962024	Fresh Air Damper Assembly	X
23	105X877	Left Side Support	X
24	147-046-* ①	Left Evaporator Support	X
25	135-128	Raceway	2
26	111X030	Outlet Airframe Assembly	X
27	105X878	Right Side Support	X
28	S143-042-* ①	Right Side Cover Plate (Outer)	X
29	135X123	Heat Shield	X
30	113-150-* ①	Top Rain Flashing	X

① NOTE: Exterior cabinet parts are manufactured with various paint color options. To insure that you receive the proper paint color, you must include the complete model and serial number of the unit for which cabinet parts are being ordered.


FUNCTIONAL COMPONENTS

Dwg. No.	Part No.	Description	WA602NA	WA602NB
1	8000-153	Compressor	X	
1	8000-154	Compressor		X
2	S900-185	Blower Assembly	X	X
3	8200-004	Fan Motor Mount	X	X
4	5151-027	Fan Blade	X	X
5	8105-039	Condenser Motor	X	X
6	5051-074	Condenser Coil	X	X
7	800-232	Cooling Capillary Assembly	X	X
8	5060-082	Evaporator Coil	X	X
9	7004-016	Air Filter 1" Throw-Away	X	X
9	7003-030	Air Filter 1" Washable	X	X
9	7004-027	Air Filter 2" Pleated	X	X
10	1171-022	1/4" Turn Fastener	X	X
11	1171-024	1/4" Turn Retainer	X	X
13	8406-055	High Pressure Switch (Solder)	X	X
NS	8406-061	Low Pressure Switch (Solder) ①	X	X
NS	8406-088	Low Ambient Control (Solder) ①	X	X
NS	1804-0106	High Pressure Switch (Flare) ①	X	X
NS	1804-0107	Low Pressure Switch (Flare) ①	X	X
NS	1804-0108	Low Ambient Control (Flare) ①	X	X

NS – Not Shown

①– Optional on these models

CONTROL PANEL




SEXP-180

Dwg. No.	Part No.	Description	WA602NA	WA602NB
1	8607-020	Low Voltage Terminal Strip	X	X
2	8607-013	Terminal Block 2 Pole	X	
2	8607-014	Terminal Block 3 Pole		X
3	8201-056	Blower Control	X	X
4	8407-034	Transformer	X	X
5	8401-002	Compressor Contactor		X
5	8401-016	Compressor Contactor	X	
6	8552-005	Outdoor Motor Capacitor		X
6	8552-058	Compressor Capacitor	X	
7	135-130	Wire Shield	X	X
8	8611-006	Ground Terminal	X	X
9	3000-978	6 Pin Connector	X	X
10	8201-034	Lockout Relay ①	X	X
11	8201-065	Lows Pressure Bypass (TDR) ①	X	X
12	8201-050	Compressor TDR ①	①	①
12	8201-067	Compressor TDR Adj. ① ③	X	X
13	8201-062	Alarm Relay ③	X	X
16	117X139	Low Voltage Box	X	X
17	117X143	Control Panel	X	X
18	8607-017	Terminal Block ③	X	X
19	8201-081	Compressor Control Module ②	X	X
NS	4095-112	Wiring Diagram	X	
NS	4095-212	Wiring Diagram		X

NS – Not Shown

- ① – Used on units with serial numbers before J98
- ② – Used on units with serial numbers after H98
- ③ – Optional

BLOWER ASSEMBLY



SEXP-178

Drawing	No.	Part No.	Description			
			900-183	900-184	900-185	900-186
1	5152-011	10 Inch Wheel (CW)			X	X
1	5152-057	9 Inch Wheel (CW)	X	X		
2	5152-012	10 Inch Wheel (CCW)			X	X
2	5152-058	9 Inch Wheel (CCW)	X	X		
3	8106-030	Blower Motor (230/208)	X		X	
3	8106-025	Blower Motor (460)		X		X
4	8552-005	Capacitor	X	X	X	X
5	8200-040	Motor Mount	X	X	X	X
6	5451-011	Grommets	6	6	6	6
7	105-880	Back Brace	X	X	X	X
8	105-881	Side Angle	4	4	4	4
9	103-389	Front Brace	X	X	X	X
10	151-101	Housing	2	2	2	2
11	144-166	Diffuser	2	2	2	2